


# 21 Clutch

21 00 006	Clutch — bleed .....	21 - 1
21 11 000	Clutch housing — remove and install .....	21 - 1
21 21 000	Clutch disc — remove and install .....	21 - 2
565	Drive plate — check for lateral runout .....	21 - 4
21 51 000	Clutch release — remove and install / replace .....	21 - 4
21 52 000	Clutch master cylinder — remove and install .....	21 - 5
010	Clutch slave cylinder — remove and install .....	21 - 5
502	Clutch master cylinder — overhaul .....	21 - 6
512	Clutch slave cylinder — overhaul .....	21 - 6
	Clutch — troubleshoot .....	21 - 7

## 21-1


### 21 00 006 BLEEDING CLUTCH

Unscrew cap on brake fluid tank.  
Remove float container (1).  
Connect bleeder.




20 21 001

Open bleeder screw on clutch slave cylinder until escaping fluid is without air bubbles. Operate clutch pedal several times during this procedure.



20 21 002

If there is still air in system after repeating the bleeding procedures several times, detach slave cylinder on transmission. Press push rod against stop in slave cylinder and release slowly. This will push back any residual air into the tank and guarantee maximum release travel. Never operate clutch pedal as long as the slave cylinder is removed.



30 21 001

### 21 11 000 REMOVING AND INSTALLING CLUTCH HOUSING

BMW M 3:  
Remove transmission see 23 00 022.


Remove DME senders.

*Important! — Installation:*

Check installed position.

Plugs must not be mixed up.

Install speed sensor (3) in bore (D) and reference mark sensor (4) with ring (5) in bore (B).  
Engine cannot be started, if plugs are mixed up.



633 23 018


*Installation:*

Check O-rings.


Install sensors with Molykote Longterm 2.

*Important!*

Face surface of DME senders must be free of grease and dirt.



633 23 019



30 21 009

Remove position sender (1).  
Unscrew clutch housing.

Use a Torx wrench\*\* to unscrew Torx bolts.

*Important! — Installation:*

Torx bolts must be installed with washers to avoid an increase in breaking-loose torque. Tightening torque\*.

\* See Specifications  
\*\* Source of Supply: HWB

## 21-3

Visually inspect clutch for cracks, wear and burnt spots.  
Pressure contact surface must be level.



316 21 013

Visually inspect clutch rivets for wear and tight fit.  
Replace a clutch with loose or worn rivets.


**Important!**  
Remove all corrosion inhibitor when installing a new clutch disc.

**Note:**  
The clutch for the version with a double mass flywheel is lower in height.




316 21 014

Place clutch disc over dowel pins.  
Tighten mounting bolts separately and uniformly to specified torque\*.  
Give transmission input shaft a light coat of Microlube GL 261\*\* in area of splines and guide pins.



316 21 013



20 21 003

**Clutch Assembly:**

- 1 Crankshaft
- 2 Grooved ball bearing
- 3 Flywheel
- 4 Drive plate\*
- 5 Thrust plate\*
- 6 Release\*
- 7 Release lever
- 8 Clutch slave cylinder

\* See Specifications  
\*\* Source of Supply: HMB


\* See Specifications

## 21-5



### 21 52 000 REMOVING AND INSTALLING CLUTCH MASTER CYLINDER

Disconnect pipe (1) to slave cylinder.

Beid 4





Unscrew cap on brake fluid tank.  
Remove float container (2).  
Draw off brake fluid in tank to lower level to connection for the filling pipe.



Remove instrument panel trim at bottom left — see 51 45 180.  
Disconnect piston rod (3) on the clutch pedal.

*Installation:*  
Adjust the clutch pedal with eccentric bolt (7) — see Group 35.

*Important! — Installation:*  
Engage over-center spring (8) in guide tab (9) on the pedal base prior to installation of the piston rod (3).



Pull out filling pipe (4).  
Unscrew bolts (5 and 6).  
Remove master cylinder.

*Installation:*  
Bleed clutch — see 21 00 006.



### 21 52 010 REMOVING AND INSTALLING CLUTCH SLAVE CYLINDER


Unscrew cap on brake fluid tank.  
Remove float container (2).  
Draw off brake fluid in tank to lower level to connection for filling pipe.

Unscrew slave cylinder on transmission.  
Remove slave cylinder.  
Disconnect pipe (3).

*Note:*

A slave cylinder with a diameter of 22.2 mm (0.874"), instead of 20.64 mm (0.809"), must be installed for the version with a double mass flywheel, to avoid contact of the release lever when the clutch pedal is floored (also refer to Service Information of Group 21).

*Installation:*  
Bleeder screw faces down.  
Install front push rod with Molykote Long-term 2.  
Bleed clutch — see 21 00 006.



# 21-7

## TROUBLESHOOTING CLUTCH

Condition	Cause	Correction
Clutch slips	<ul style="list-style-type: none"> <li>a) Clutch contact pressure* insufficient</li> <li>b) Liner* seriously worn</li> <li>c) Liner splattered with oil – transmission or crankshaft seal faulty</li> <li>d) Clutch was overheated</li> <li>e) Clutch not an original BMW part</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace clutch 21 21 000</li> <li>b) Replace drive plate 21 21 000</li> <li>c) Replace faulty seal and drive plate</li> <li>d) Replace clutch 21 21 000</li> <li>e) Install original BMW parts</li> </ul>
Clutch grabs	<ul style="list-style-type: none"> <li>a) Liner* not as specified</li> <li>b) Liner splattered with oil</li> <li>c) Release pressure one-sided</li> <li>d) Pressure plate pressing crooked</li> <li>e) Crankshaft not aligned with transmission input shaft</li> <li>f) Engine and transmission suspension faulty</li> <li>g) Drive plate not an original BMW part</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace drive plate 21 21 000</li> <li>b) Replace drive plate 21 21 000</li> <li>c) Check release lever</li> <li>d) Replace pressure plate 21 21 000</li> <li>e) Check centering surfaces on engine and transmission</li> <li>f) Replace engine and transmission suspension</li> <li>g) Install original BMW parts</li> </ul>
Clutch does not release	<ul style="list-style-type: none"> <li>a) Drive plate wrenched excessively or liner broken</li> <li>b) Drive plate has excessive lateral runout*</li> <li>c) Liner rusted on flywheel</li> <li>d) Drive plate seized on transmission input shaft</li> <li>e) Bearing in crankshaft for transmission input shaft faulty</li> <li>f) Air in clutch hydraulic system</li> <li>g) Tangential leaf springs of clutch bent off</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace drive plate 21 21 000</li> <li>b) Straighten or replace drive plate 21 21 565</li> <li>c) Clean flywheel, roughen liner surfaces with emery cloth</li> <li>d) Service drive plate on transmission input shaft, replacing damaged parts if necessary</li> <li>e) Replace bearing in crankshaft 11 21 571</li> <li>f) Bleed clutch 21 00 006</li> <li>g) Replace clutch 21 21 000</li> </ul>
Clutch noise	<ul style="list-style-type: none"> <li>a) Unbalance* of clutch and drive plate excessive</li> <li>b) Torsional damper defective</li> <li>c) Clutch release faulty</li> <li>d) Bearing in crankshaft for transmission input shaft faulty</li> <li>e) Clutch rivets loose</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace clutch and/or drive plate 21 21 000</li> <li>b) Replace drive plate 21 21 000</li> <li>c) Replace clutch release</li> <li>d) Replace bearing in crankshaft 11 21 571</li> <li>e) Replace clutch 21 21 000</li> </ul>

\* See Specifications

# 23 Manual Transmission

## Getrag 240 Five Speed Manual Transmission with Overdrive

23 00 022	Layout drawing - transmission	23 - 1
23 11 013	Layout drawing - shift mechanism	23 - 2
23 12 053	Transmission - remove and install	23 - 3
083	Transmission - exchange	23 - 3b
503	Transmission case front section - remove and install / seal	23 - 4
503	Guide sleeve for clutch release - remove and install	23 - 5
554	Radial oil seal for output flange - replace	23 - 6
703	Radial oil seal for selector shaft - replace	23 - 6
23 21 503	Radial oil seal for input shaft - replace	23 - 7
23 23 505	Input and output shaft assembly - remove and install	23 - 8
	Output shaft - replace	23 - 13
	Bearings of all transmission shafts - replace	23 - 18
	Synchronization - disassemble and assemble	23 - 22

# 23 Manual Transmission

## GETRAG 260 Five Speed Manual Transmission with Overdrive

Layout drawing — transmission .....	23 - 165
Layout drawing — shift mechanism .....	23 - 166
23 00 022 Transmission — remove and install .....	23 - 167
032 Transmission — exchange .....	23 - 168a
23 11 013 Transmission case front section — remove and install / seal .....	23 - 169
623 Guide sleeve for clutch release — remove and install .....	23 - 170
23 12 053 Radial oil seal for output flange — replace .....	23 - 172
083 Radial oil seal for selector shaft — replace .....	23 - 173
503 Radial oil seal for input shaft — replace .....	23 - 173a
23 13 010 Vibration damper — remove and install / replace .....	23 - 173a

# 23 Manual Transmission


## GETRAG 265/6 Five Speed Manual Transmission with Overdrive

Layout drawing – transmission .....	23-300
Layout drawing – shift mechanism .....	23-301
23 00 022 Transmission – remove and install .....	23-302
032 Transmission – exchange .....	23-304
23 11 013 Transmission case front section – remove and install / seal .....	23-305
522 Transmission case rear section – remove and install / seal .....	23-307
610 Guide sleeve for clutch release – replace .....	23-310
623 Cover with guide sleeve for clutch release – remove and install / seal .....	23-311
23 12 053 Radial oil seal for output flange – replace .....	23-311
083 Radial oil seal for selector shaft – replace .....	23-312
503 Radial oil seal for input shaft – replace .....	23-312



# 23-1

## ASSEMBLY DRAWING OF GETRAG 240 FIVE SPEED OVERDRIVE MANUAL TRANSMISSION



- 1 First gear
- 2 Second gear
- 3 Third gear


- 4 Fourth gear
- 5 Fifth gear
- R Reverse gear

- 6 Input shaft
- 7 Output shaft
- 8 Layshaft

30 23 001


**23 00 022 REMOVING AND INSTALLING TRANSMISSION**

Remove exhaust assembly — see 18 00 020.  
 Unscrew heat shield.




30 23 105

Unscrew bolts.  
 Replace stop nuts.



20 23 097

**Installation:**  
 Tighten nuts with a standard 17 mm socket together with a torque wrench.  
 Tightening torque\*.  
**Important!**  
 Only tighten nuts (newer bolts) to avoid stress in Giubo coupling.




20 23 098

**Version with Threaded Ring:**  
 Loosen threaded ring (1) several turns.  
**Installation:**  
 Tighten threaded ring (1) with Special Tool 26 1 040 after finishing installation.  
 Tightening torque\*.



30 23 125

\* See Specifications




30 23 106

Unscrew center mount.  
**Installation:**  
 Preload center mount forward by distance (A) = 4 to 6 mm (0.157 to 0.236").  
 Tightening torque\*.  
 Bend propeller shaft down and pull off of centering pin.  
**Important!**  
 Don't let the propeller shaft fall into the joints. Suspend propeller shaft from car on a piece of wire.



30 23 114


Lift out circlip (1) and remove washer (2).  
 Pull out shift rod.  
 Unscrew shift console on transmission.  
**Important!**  
 Self-locking bolts — bolts will be hard to unscrew.  
**Installation:**  
 Always replace bolts.  
 When tightening make sure brackets are horizontal to the shift console (shift lever noise).  
 Tightening torque\*.  
 Pull off wires on reverse gear switch.



30 23 134

**Version with Shift Arm:**  
 Lift spring (1) out of tab (2) on the case with a screwdriver and swing up.  
 Pull out bearing pin.  
**Installation:**  
 Lubricate bearing pin lightly with Molykote Longterm 2.


Remove clutch slave cylinder.  
 Line remains connected.  
**Installation:**  
 Bleeder screw faces down.




30 23 107

\* See Specifications


## 23-5




Unscrew oil drain plug.  
Mount case front section.  
Align layshaft through bore for oil drain plug that roller bearing of layshaft slides into bearing shell.  
Mount case front section.  
Tightening torque\*.  
Install lockpin and reverse gear switch.




Install spacer and circlip.  
Take up play between bearing race and circlip to 0 ... 0.09 mm (0 ... 0.0035").




23 11 623 REMOVING AND INSTALLING GUIDE SLEEVE FOR CLUTCH RELEASE  
—TRANSMISSION REMOVED—  
Lift out spring (1) and remove release lever (2) with thrust bearing (3).




*Installation:*  
Pack lubricating groove N with Molykote Longterm 2.  
Coat guides F and bearings L with Molykote Longterm 2.  
Non-conformance could cause release bearing to seize on guide sleeve.



Detach guide sleeve.  
*Important!*  
Spacer.  
*Installation:*  
Install guide sleeve with Loctite No. 573.  
Sealing surface must be thoroughly clean and dried of oil.



*Installation:*  
Take up play to 0 ... 0.09 mm (0 ... 0.0035").  
Determine thickness of spacer.  
Measure distance (B) from guide sleeve protrusion to inside surface.




Measure distance (C) from guide sleeve protrusion to outside surface.  
Example:  
B 4.0 mm (0.157")  
— C 2.6 mm (0.102")  
1.4 mm (0.055") spacer thickness

## 23-3b

### 23 00 032 INSTALLING EXCHANGE TRANSMISSION

Remove transmission – see 23 00 022.

Transmission Identification:  
BMW code\* die-stamped on front case section.



630 23 278

BMW code\* marked on front case section (label).




30 23 301


Transmission ZF S 5 - 16:

**Important!**  
Mount vent (1) prior to installation of the transmission (red label).

Pull vent (1) and sleeve (2) off of the shift shaft.  
Lift out cap (3) and install vent (1).



30 23 302



316 23 024

Transfer spring (1) and release lever (2) with release (3).

**Note:**  
Coat transmission input shaft lightly with MicroLube GL 261\*\* in area of splines and guide pins.

**Installation:**  
Fill lubricating groove (N) with Molykote Longterm 2.  
Coat guides (F) and bearings (L) lightly with Molykote Longterm 2.  
Non-conformance could cause seizure of the bearing on the guide sleeve.



316 23 025

Transfer shift rod joint.  
Push back locking sleeve (1).  
Drive out dowel pin (2).

**Note:**  
Check installed position of the shift rod joint – the offset end of the shift rod joint must face right as seen looking forward in the car.



630 23 280

Transfer rubber mounts, exhaust carrier and backup light switch.

**Important!**  
Transmissions are supplied with oil since 1.86. Consequently it is only necessary to check the oil level after installation of a transmission.

\* See Parts Microfiche

630 23 281

\*\* Source of Supply: HWB

# 23-7

## 23 12 503 REPLACING RADIAL OIL SEAL FOR INPUT SHAFT - TRANSMISSION REMOVED -



Remove guide sleeve 23 11 623.  
Remove radial oil seal.

320 23 048



00 5 500

23 1 360

320 23 049

Drive in radial oil seal with Special Tools  
23 1 360 and 00 5 500.  
Open end faces transmission case.  
Lubricate sealing lip with oil.


## 23-9

Remove three springs.



Drive out pin (10) in 3rd/4th gear selector fork.

*Installation:*  
Replace pin.




Knock out 3rd/4th gear selector rod forward.  
*Important!*  
Lockpin (11) in selector rod.



Engage 2nd and reverse gears by pushing 1st/2nd and 5th/reverse gear selector rods forward.



231 050



Press input shaft, output shaft and layshaft out of case rear section with Special Tool 23 1 050.


*Important!*  
To avoid damage on sealing surface, use a piece of wood, aluminum or similar material between claws and sealing surface.



*Important!*  
Be careful not to clamp selector rods and layshaft while pressing out parts.  
Layshaft must not tilt off during this step.  
*Installation:*  
Check condition of all bearings, replacing if necessary.



*Installing:*  
Install 3rd/4th gear selector fork and 1st/2nd as well as 5th/reverse gear selector rods with selector forks.



Remove all detent and locking balls in case rear section.  
Install roller bearings with large diameter end facing out.  
Lubricate lockpin and locking lever with oil.

## 23-11

Install end cover after coating with Loctite No. 573  
Install end cover with Loctite No. 573




30 23 041

Drive pin out of selector arm.




30 23 042

Hold 4 rollers in position with grease.  
Slide in selector shaft and install selector arm  
(1) at same time.  
*Important!*  
Opening in selector shaft faces out.




30 23 043

Drive in 6 x 26 mm pin (counterhold).



30 23 044

23 1 240



30 23 045

Lubricate sealing lips of radial oil seal with oil.  
Drive in radial oil seal with Special T tool  
23 1 240.



30 23 046


Install selector rail.  
Groove (1) in selector rail faces up.  
Install operating lever (5) with notch facing up  
and toward selector rail.  
Install pin (4).



30 23 047

Coat case rear section in area of reverse gear shaft  
with Loctite No. 573.  
Surface must be thoroughly clean and dried of  
oil.

Install shaft with needle bearing and reverse gear.



30 23 048

23 21 554 REPLACING OUTPUT SHAFT  
 - Output Shaft Removed -

Pull off input shaft (1), brass synchronomesh ring (2) and needle bearing (3).


Note:

Synchronization:  
 It is recommended to mark synchronomesh rings and their corresponding gear wheels when disassembling the output shaft, in order to avoid mixing up synchronomesh rings.



30 23 051

Pull off 5th gear (4), brass synchronomesh ring (5) and needle bearing (6).



30 23 052

Lift out circlip (7).  
 Remove spacer (8).

Installation:  
 Always replace circlip.




30 23 053

Installation:  
 Adjust play between circlip and guide sleeve to 0 ... 0.09 mm (0 to 0.0035").




30 23 054



30 23 055


Important!  
 Operate 3rd/4th gear operating sleeve by hand in direction of 3rd gear.  
 Press off 3rd gear with guide and operating sleeves, using Special Tool 23 1 490.  
 Remove needle bearing.  
 Pressing-off force\*.

Press off bearing sleeve and 2nd gear with Special Tool 23 1 490.  
 Remove nickel-plated synchronomesh ring and needle bearing.




30 23 056

Important!  
 Remove circlip (10) before pressing off 1st gear.  
 Installation:  
 Always replace circlip.



30 23 057

Press off 1st gear with guide and operating sleeve, using Special Tool 23 1 490.  
 Remove needle bearing.  
 Pressing-off force\*.



30 23 058

\* See Specifications



23 1 290—



30 23 067

Press on guide sleeve to fit tight with Special Tool 23 1 290. Pressing-on force\*.

**Important!**  
Make sure tabs on synchronomesh ring are aligned with openings in guide sleeve while installing.


Move operating sleeve in direction of 1st gear.  
Adjust guide sleeve to remove all play. Circlips are available from Parts in different thicknesses from 1.7 to 2.0 mm (0.067 to 0.079"). Install circlip (10).



30 23 068

Install needle bearing, nickle-plated synchronomesh ring and 2nd gear.

**Important!**  
Collar for bearing sleeve on output shaft must protrude slightly. If necessary, check circlip (1) for proper fit.



630 23 253

Heat bearing sleeve to approx. 80°C (175°F) and install on output shaft.



30 23 071

\* See Specifications




30 23 143

**Version with Thrust Washer:**  
Install thrust washer (1) and ball (2). Heat bearing sleeve (3) without collar to about 80°C (175°F) with a hot air blower and install on output shaft.

Install needle bearing, 3rd gear and synchronomesh ring.  
Install guide and operating sleeves on splines with the groove facing 4th gear.

**Note:**  
Version with 2 Grooves:  
Grooves face 3rd gear.



30 23 072

Press on guide sleeve to fit tight with Special Tool 23 1 290.


**Important!**  
Make sure while pressing on that tabs on the synchronomesh ring are aligned with openings in the guide sleeve. Install shim and circlip. Pressing-on force\*.



30 23 073

\* See Specifications

# 23-17



Layout of Gear Set and Bearings


- 1 Circlip
- 2 Spacer
- 3 Spacer
- 4 Bearing
- 5 Input shaft with 4th gear
- 6 Synchromesh ring
- 7 Needle bearing
- 8 Circlip
- 9 Spacer
- 10 Dog
- 11 Ball
- 12 Spring
- 13 Guide sleeve
- 14 Operating sleeve
- 15 3rd gear
- 16 Needle bearing
- 17 Spacer
- 18 Needle bearing
- 19 2nd gear
- 20 Synchromesh ring
- 21 Circlip
- 22 Guide sleeve
- 23 Synchromesh ring
- 24 Operating sleeve
- 25 1st gear
- 26 Needle bearing
- 27 Output shaft
- 28 Reverse gear
- 29 Synchromesh ring
- 30 Guide sleeve
- 31 Circlip
- 32 Needle bearing
- 33 5th gear
- 34 Bearing
- 35 Spacer
- 36 Spacer
- 37 Speedometer drive gear
- 38 Output flange
- 39 Collar nut
- 40 Lockplate
- 41 Circlip
- 42 Spacer
- 43 Bearing
- 44 Layshaft
- 45 Bearing

30 23 100

## 23-19

Remove selector arm from above.

**Important!**  
Roller.




23 1 250

30 23 082

**Installation:**

Install spring (2).  
Install selector arm with Special Tool 23 1 250.  
Swing out selector arm with roller over locking lever (4).




2

4

30 23 083

Position end of spring (3) above high spot.  
In this position push down on selector arm (don't knock down).  
Secure selector arm with socket head bolt tightened with correct torque\* before removing the special tool.  
Install socket head bolt with a locking compound\*\*.




3

4

30 23 084

Unscrew bolt.  
Remove locking lever (4) and shim (5).  
Remove bearing holder (6).

**Installation:**  
Install bolt with a large washer.



4

5

6

30 23 085

**Installation:**  
Check installed position of locking lever (4) and thrust pin (7).




4

7

30 23 086

Lift out radial oil seal.  
Drive out grooved ball bearing with Special Tools 23 1 120 and 00 5 500.

**Important!**  
Shim X.



00 5 500

23 1 120

30 23 087

Determine thickness of shim X.  
Measure distance (A).



A

30 23 088

Measure distance (B).


**Example:**  
A 17.5 mm (0.689")  
- B 17.0 mm (0.669")  
X 0.5 mm (0.020") shim thickness

30 23 089

\* See Specifications  
\*\* Source of Supply: HWB


## 23-21

Install front case section and mount  
with two bolts opposite each other.  
Center front case section with dowel  
pins.  
Unscrew oil filler plug (1).




30 23 097

Clamp on holder with dial gage.  
Dial gage tip must bear on tooth of  
layshaft.



30 23 098

Check layshaft axial play through bore  
for the oil filler plug.  
Axial play = 0.13 to 0.23 mm (0.005 to  
0.009").  
If correction is necessary, bearing shell  
must be removed again and a shim of  
different thickness installed.



30 23 099


Install gear wheel set.  
Determine thickness of drive pinion  
shim.  
Install old shim and circlip.  
Adjust play to 0 ... 0.09 mm (0 to  
0.0035"),  
Determine thickness of shim for guide  
sleeve — see 23 11 623.



30 23 013

# 23 - 101

ASSEMBLY DRAWING OF ZF - S5 - 16 FIVE SPEED OVERDRIVE MANUAL TRANSMISSION



- 1 First gear
- 2 Second gear
- 3 Third gear

- 4 Fourth gear
- 5 Fifth gear
- R Reverse gear


- 6 Input shaft
- 7 Output shaft
- 8 Layshaft

30 23 201

## 23-103


### 23 11 014 REMOVING AND INSTALLING SEALING TRANSMISSION CASE FRONT SECTION

Remove transmission 23 00 022.  
Mount Special Tool 23 0 090 on Special Tool 00 1 490.  
Mount transmission on special tool assembly.  
Drain oil.




30 23 203

Remove guide sleeve 23 11 624.  
Lift out circlip (1).




30 23 204

Unscrew backup light switch.  
Drive back cylindrical pins.  
Unscrew bolts.



30 23 205

Pull off case front section with Special Tool 23 1 460 and 33 1 301.



30 23 206

Pull off case front section.  
*Installation:*  
Replace gasket.




30 23 207

*Important!*  
*Installation:*  
Magnet (2) in case rear section.  
Clean magnet.




30 23 208

Drive out end cap (3).  
*Installation:*  
Replace end cap and insert with Loctite No. 573.



30 23 209


Drive out grooved ball bearing in direction of clutch housing.



30 23 210


## 23-105

Press grooved ball bearing on to input shaft and into case front section with Special Tools 23 1 007, 23 1 000 and 23 1 006.  
*Important!*  
Insert Special Tools 23 1 006 that flat side faces input shaft.




Drive on grooved ball bearing further simultaneously with light hammer knocks. Install circlip and reverse gear switch.


## 23 - 107



**23 12 054 REPLACING RADIAL OIL SEAL FOR OUTPUT FLANGE**  
 Unscrew propeller shaft at front end and on center mount (see 23 00 022).  
 Remove lockplate.  
*Installation:*  
 Lock lockplate in groove.




Apply Special Tool 23 1 200.  
 Hold output flange with Special Tool 23 0 020.  
 Unscrew collar nut with Special Tool 23 1 210.  
*Installation:*  
 Tightening torque\*.  
 Install collar nut with a bolt cement\*\*.



Pull out output flange with Special Tool 33 1 150.




\* See Specifications  
 \*\* Source: HMB




*Installation:*  
 Lubricate sealing lip with oil.  
 Drive in radial oil seal with Special Tool 23 2 160.



**23 12 084 REPLACING RADIAL OIL SEAL FOR SELECTOR SHAFT**  
 Unscrew propeller shaft at front end and on center mount (see 23 00 022).  
 Unscrew output flange (see 23 12 054).  
 Lift out locking sleeve (1).  
 Drive out pin (2) upwards.



Lift out radial oil seal (3).




Lubricate sealing lips of radial oil seal with oil.  
 Drive in radial oil seal with Special Tool 23 1 240.




# 23-109

## 23 21 504 REMOVING AND INSTALLING INPUT AND OUTPUT SHAFT ASSEMBLY

Remove case front section 23 11 014.  
 Remove lockplate.  
 Apply Special Tool 23 1 200.  
 Hold output flange with Special Tool 23 0 020.  
 Unscrew collar nut with Special Tool 23 1 210.




Pull off output flange with Special Tool 33 1 150.




Remove end caps (1 ... 3).  
*Important!*  
 Spring force.  
*Installation:*  
 Replace end caps.




Remove three springs.




Pull out three stop pins with a circlip pliers as far as possible (stem locks would have to be taken off before stop pins could be pulled out completely).




Drive pins (4 and 5) out of selector fork for 3rd/4th gear (counterhold).




Push back leaf spring (6) for reverse gear far enough with Special Tool 23 2 170 until selector arm (7) is accessible.  
 It should be possible to move selector shaft back and forth easily.




Swing selector arm (8) out of groove in selector rod.






Remove reverse gear.  
Slide in 3rd/4th gear selector rod with openings (2) facing up.


Drive in pins for 3rd/4th gear selector forks (counterhold).



Remove Special Tool 23 2 170 for leaf spring.  
**Important!**  
Roller (3) on leaf spring (6) must engage in selector arm (7).



Install bolt (9) for operating lever.  
Tip of bolt must engage in bore of operating.  
Tightening torque\*.




\* See Specifications




Insert 3 springs for stop pins.  
Install and lock new end caps by punching.


Install thrust washer (1) on case with angle (2) in upper opening.



Insert reverse gear with long collar facing case, two needle bearings and shaft.



Place insulator on bolt.  
Install bolt (9).  
Install new bolt lock.  
Tightening torque\*.




\* See Specifications

## 23-113

### 23 21 555 REPLACING OUTPUT SHAFT — Output Shaft Removed —


Pull off input shaft (1), synchronesh ring (2) made of brass and needle bearing (3).



30 23 245

Lift out circlip (4).

*Installation:*  
Always replace circlip.




30 23 246

*Installation:*  
Adjust guide sleeve with circlip (4) to take up all play.  
Circlips are available from Parts in different thicknesses.




30 23 247

Press 3rd gear with guide and sliding sleeves off of output shaft with Special Tool 23 1 490. Remove needle bearing.



30 23 248


Press bearing sleeve, thrust washer and 2nd gear off of output shaft with Special Tool 23 1 490. Remove needle bearing and sintered steel synchronesh ring.



30 23 249


**Important!**  
Circlip (5) must be removed before pressing off 1st gear.

*Installation:*  
Always replace circlip.




30 23 250

Press 1st gear with guide and sliding sleeves off of output shaft with Special Tool 23 1 490. Remove needle bearing.



30 23 251


Press thrust washer and 5th gear off of output shaft with Special Tool 23 1 490. Remove brass synchronesh ring and needle bearing.



30 23 252

## 23-115


**Install needle bearing, 1st gear and sintered steel synchromesh ring.**  
Install guide sleeve and sliding sleeve with narrow collar facing 1st gear.



30 23 261


Press on guide sleeve to fit tight with Special Tool 23 1 290.

**Important!**  
When pressing on make sure that short tabs of synchromesh ring are aligned with groove in thrust pieces.



30 23 262

Move sliding sleeve in 1st gear direction. Adjust guide sleeve to be without play. Circlips are available from Parts in different thicknesses.  
Install circlip (5).




30 23 263

Install sintered steel synchromesh ring with short tabs of synchromesh ring in groove of pressure pieces.  
Install needle bearing and 2nd gear.




30 23 264

**Important!**  
Output shaft collar for thrust washer must protrude slightly.  
If necessary, check circlip (5) for correct fit.  
Heat thrust washer (8) to approx. 80° C (175° F) and install on output shaft.




30 23 265

Heat bearing sleeve (9) to approx. 80° C (175° F) and install on output shaft.



30 23 266


Install needle bearing, 3rd gear and brass synchromesh ring.  
Install guide sleeve and sliding sleeve with long collar facing 3rd gear.  
Install circlip.



30 23 267

Press on guide sleeve to fit tight with Special Tool 23 1 290.


**Important!**  
When pressing on make sure that short tabs of synchromesh ring are aligned with groove of pressure pieces.  
Install circlip.



30 23 268


# 23-117

DRAWING OF GEAR SET AND BEARINGS




- 1 Circlip
- 2 Spacer
- 3 Circlip
- 4 Grooved ball bearing
- 5 Input shaft
- 6 Synchromesh ring
- 7 Roller bearing
- 8 Circlip
- 9 Sliding sleeve
- 10 Pressure piece
- 11 Ball
- 12 Spring
- 13 Guide sleeve
- 14 Synchromesh ring
- 15 3rd gear
- 16 Needle bearing
- 17 Bearing sleeve
- 18 Thrust washer
- 19 2nd gear
- 20 Synchromesh ring
- 21 Circlip
- 22 Sliding sleeve
- 23 Guide sleeve
- 24 Synchromesh ring
- 25 1st gear
- 26 Needle bearing
- 27 Output shaft
- 28 Needle bearing
- 29 Reverse gear
- 30 Synchromesh ring
- 31 Balls (six)
- 32 Guide sleeve
- 33 Sliding sleeve
- 34 Circlip
- 35 Needle bearing
- 36 5th gear
- 37 Thrust washer
- 38 Bolt
- 39 Clamp
- 40 Grooved ball bearing
- 41 Radial oil seal
- 42 Output flange
- 43 Lockplate
- 44 Collar nut
- 45 Roller bearing
- 46 Circlip
- 47 4th gear
- 48 3rd gear
- 49 Layshaft
- 50 5th gear
- 51 Thrust washer
- 52 Reverse gear
- 53 Needle bearing
- 54 Shaft
- 55 Seal
- 56 Bolt
- 57 Bolt lock


## 23 - 119




Unscrew bolts.  
Remove clamps (2 and 3).  
*Installation:*  
Tightening torque\*.




Lift out radial oil seal.  
Drive out grooved ball bearing with Special  
Tools 23 1 120 and 00 5 500.




Drive in radial oil seal with Special Tool  
23 2 160.  
Lubricate sealing lip with oil.




\* See Specifications



**Layshaft:**  
Destroy roller cage of bearing.  
Remove cage with rollers.



Pull out bearing outer race (1) with Special  
Tool 00 8 550 and support.  
*Important!*  
Use a flat iron bar or similar item between  
support and sealing surface to avoid damage  
on sealing surface.



Heat case rear section in area of roller bearing  
to about 80° C (176° F) with a hot air blower.  
Drive in roller bearing with Special Tool  
23 2 220.


# 23-121

## TROUBLESHOOTING MANUAL TRANSMISSION

Condition	Cause	Correction
Oil on clutch bell housing	<ul style="list-style-type: none"> <li>a) O-ring in guide flange leaks</li> <li>b) Radial oil seal for input shaft leaks</li> <li>c) Gasket on end cover (crankcase leaks)</li> <li>d) Radial oil seal for crankshaft leaks</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace O-ring 23 11 590</li> <li>b) Replace radial oil seal 23 12 521</li> <li>c) Replace gasket 11 14 611</li> <li>d) Replace radial oil seal 11 14 611</li> </ul>
Oil on output flange	<ul style="list-style-type: none"> <li>a) Radial oil seal for output shaft leaks</li> <li>b) Radial oil seal for selector shaft leaks</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace radial oil seal 23 12 051</li> <li>b) Replace radial oil seal 23 12 081</li> </ul>
Transmission leaks between front and rear sections	<ul style="list-style-type: none"> <li>a) Gasket defective</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace gasket 23 11 000</li> </ul>
Oil on speedometer drive	<ul style="list-style-type: none"> <li>a) O-ring defective</li> <li>b) Radial oil seal in bush defective</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace O-ring 23 22 100</li> <li>b) Replace bush</li> </ul>
Oil on vent	<ul style="list-style-type: none"> <li>a) Oil level too high</li> <li>b) Wrong oil grade (excessive foaming)</li> </ul>	<ul style="list-style-type: none"> <li>a) Correct oil level</li> <li>b) Replace oil</li> </ul>
Gear does not stay in — jumps out	<ul style="list-style-type: none"> <li>a) Sliding sleeve worn, guide rail defective, springs broken</li> <li>b) Sliding sleeves for 1st/2nd and 3rd/4th gear mixed up</li> <li>c) Shift console loose</li> <li>d) Selector forks worn</li> <li>e) Output flange loose</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace damaged parts 23 23 503</li> <li>b) Install sliding sleeves correctly 23 23 503</li> <li>c) Tighten shift console</li> <li>d) Replace selector forks 23 31 501</li> <li>e) Tighten output flange</li> </ul>

# 23-165

ASSEMBLY DRAWING OF GETRAG 260 FIVE SPEED OVERDRIVE MANUAL TRANSMISSION



630 23 301

- 1 First gear
- 2 Second gear
- 3 Third gear

- 4 Fourth gear
- 5 Fifth gear
- 6 Reverse gear

- 6 Input shaft
- 7 Output shaft
- 8 Layshaft



## 23-167

### 23 00 022 REMOVING AND INSTALLING TRANSMISSION


Remove exhaust assembly – see 18 00 020.

Cars with Four Wheel Drive:

Remove transfer box – see 27 10 010.

UnscREW heat shield.


UnscREW connector (2) and heat shield (3).



30 24 113

**Installation:**  
Also mount holder (4).

UnscREW joint disc on transmission.  
Always replace stop nuts.




20 23 0971

**Installation:**

Tighten nuts with a standard 17 or 19 mm wrench socket together with a torque wrench.  
Tightening torque\*.

**Important!**

Only tighten nuts on flange end, whenever possible by design, to avoid tension in the joint disc.



20 23 004

Version with Integrated Vibration Damper (1):  
Vibration damper (1) is mounted on the output flange with press-fit bolts.

UnscREW nuts on joint disc.


Pull off joint disc only after lowering the transmission.

**Installation:**

Tightening torque\*.


**Note:**

BMW 325 i:  
The vibration damper is mounted together with the joint disc.



30 23 130

\* See Specifications




30 23 120

Loosen threaded ring (1) several turns.

**Installation:**

Tighten threaded ring (1) with Special Tool 26 1 040 after finishing installation.  
Tightening torque\*.



30 23 106

UnscREW center mount.

**Installation:**

Preload center mount forward by distance (A) = 4 to 6 mm (0.157 to 0.236"). Bend propeller shaft down and pull it off of the centering pin.

**Important!**

Don't let the propeller shaft fall into joints. Suspend propeller shaft from car on pieces of wire.

Lift out retainer (1) and take off washer (2).  
Pull out shift rod.




20 23 006

UnscREW shift console on transmission.

**Important!**  
Self-locking bolts – they will be hard to unscREW.

**Installation:**

Always replace bolts.  
Make sure consoles are horizontal to the shift console while tightening (shift lever noise).



20 23 007

\* See Specifications


## 23-168a

### 23 00 032 INSTALLING EXCHANGE TRANSMISSION

Remove transmission - see 23 00 022.


Transmission Identification:  
BMW code\* on front case section (die-stamped or label).

Transmission Type:  
Getrag 260.




Transfer spring (1) and release lever (2) with release (3).

Note:  
Give transmission input shaft a light coat of Mircrolupe GL 261\*\* In area of splines and guide pins.



#### Installation:

Fill lubricating groove (N) with Molykote Longterm 2.  
Coat guides (F) and bearings (L) lightly with Molykote Longterm 2.  
Non-conformance could cause seizure of bearing on the guide sleeve.



Transfer shift rod joint.  
Slide back locking sleeve (1).  
Drive out cylindrical pin (2).

Note:  
Check installed position of shift rod joint - offset end of shift rod joint on the right as seen looking forward in car.

Transfer rubber mounts, exhaust carrier and backup light switch.

Important!  
Transmissions are supplied with oil since 1.86, so that it is only necessary to check the oil level after installation of the transmission.



\* See Parts Microfiche  
\*\* Source of Supply: HWB

# 23-170




630 23 204

Remove grooved ball bearing for input shaft.  
*Important!*  
 Inner race of grooved ball bearing has a protrusion.  
 Protrusion faces gear shaft.


Unscrew oil drain plug.  
 Coat sealing surface with Loctite No. 573\*\*.  
 Sealing surface must be thoroughly clean and dried of oil.

Mount case front section.  
 Align layshaft through bore for oil drain plug that roller bearing of layshaft slides into bearing shell.  
 Bolt case front section.  
 Tightening torque.  
 Install lookpin and reverse gear switch.



630 23 205


Heat\* bearing inner race and case front section in area of grooved ball bearing with a hot air blower.  
 Push on grooved ball bearing as far as possible.  
 Inner race protrusion faces gear set.



630 23 206

Press grooved ball bearing on to input shaft and into case front section with Special Tools 23 1 007, 23 1 000 and 23 1 006.

*Important!*  
 Insert Special Tool 23 1 006 that flat sides face input shaft.




23 1 000

23 1 007

23 1 006

630 23 207

\* See Specifications  
 \*\* Source: HWB



630 23 208


Keep driving on grooved ball bearing simultaneously with light hammer knocks.

Install spacer and circlip.  
 Adjust play between bearing inner race and circlip to 0 ... 0.09 mm (0 ... 0.0035").




630 23 209

23 11 623 REMOVING AND INSTALLING GUIDE SLEEVE FOR CLUTCH RELEASE — TRANSMISSION REMOVED —  
 Lift out spring (1) and remove release lever (2) with thrust bearing (3).



30 23 014

*Installation:*  
 Pack lubricating groove N with Molykote Longterm 2.  
 Coat guides F and bearings L with Molykote Longterm 2.  
 Non-conformance could cause release bearing to seize on guide sleeve.



N

630 21 029

## 23-172


### 23 12 053 REPLACING RADIAL OIL SEAL FOR OUTPUT FLANGE

Unscrew propeller shaft — see 23 00 022.  
 Lift out lockplate (1).  
*Installation:*  
 Replace lockplate.



Apply Special Tool 23 1 200.  
 Hold output flange with Special Tool 23 0 020.  
 Unscrew collar nut with Special Tool 23 1 210.


*Installation:*  
 Install collar nut with a bolt cement\*\*.  
 Tightening torque\*.



Version with Integrated Vibration Damper:  
 Hold output flange with Special Tool 23 1 320.



If too difficult, pull off output flange with  
 Special Tool 33 1 150.




Pull out radial oil seal with Special Tool  
 00 5 010.



Lift out radial oil seal.  
 Drive in radial oil seal with Special Tools  
 23 1 380 and 00 5 500.

*Installation:*  
 Lubricate sealing lips with oil.  
 Bolt on output flange to specified tightening  
 torque\*.  
 Install collar nut with a bolt cement\*\*.



\* See Specifications  
 \*\* Source of Supply: HWB

\* See Specifications  
 \*\* Source of Supply: HWB

## 23-173a

### 23 13 010 REMOVING AND INSTALLING OR REPLACING VIBRATION DAMPER

Unscrew propeller shaft at front and center  
mount, see 23 00 022.

Lift out lockplate.

Apply Special Tool 23 1 200.


Hold output flange with Special Tool  
23 1 320.

Unscrew collar nut with Special Tool  
23 1 210.


*Installation:*

Tightening torque\*.


Install collar nut with a bolt cement,  
Loctite No. 270.



Pull off output flange with Special Tool  
33 1 150.



Vibration damper (1) is mounted on the output  
flange with three staybolts.  
Press staybolts out of output flange.  
Apply a suitable piece of round iron bar on  
both sides.




Screw on nuts to avoid damaging the threads.  
Press out staybolts.  
Take off vibration damper.



30 23 132

Mount the output flange with its bore on a  
suitable piece of pipe.  
Mount vibration damper (1) with the staybolts.  
Press in the staybolts.  
*Important!*  
Press in staybolts with the flat side facing the  
vibration damper.



30 23 133

## 23-175

Remove three springs.



Drive out pin (10) in 3rd/4th gear selector fork.

*Installation:*  
Replace pin.



Knock out 3rd/4th gear selector rod forward.

*Important!*  
Lockpin (11) in selector rod.



Engage 2nd and reverse gears by pushing 1st/2nd and 5th/reverse gear selector rods forward.



23 1 050

Press input shaft, output shaft and layshaft out of case rear section with Special Tool 23 1 050.

*Important!*  
To avoid sealing surface damage, use a piece of wood, aluminum or similar material between claws and sealing surface.

*Important!*  
Be careful not to clamp selector rods and layshaft while pressing out parts.

*Installation:*  
Check condition of all bearings, replacing if necessary.




630 23 228

*Installing:*  
Install 3rd/4th gear selector fork and 1st/2nd as well as 5th/reverse gear selector rods with selector forks.  
Check thrust washer (1).




630 23 229

Remove all detent and locking balls in case rear section.  
Install roller bearings with large diameter end facing out.  
Lubricate lockpin and locking lever with oil.



630 23 230

## 23-177




Install end cap after coating with Loctite No. 573\*.  
Install end cover with Loctite No. 573

Drive pin out of selector arm.





30 23 042

Hold four rollers in position with grease.  
Slide in selector shaft and install selector arm (1) at same time.  
*Important!*  
Opening in selector shaft faces out.




Drive in 6 x 26 mm pin (counterhold).




Lubricate sealing lips of radial oil seal with oil.  
Drive in radial oil seal with Special Tool 23 1 240.

Install selector rail.  
Groove (1) in selector rail faces up.  
Install operating lever (5) with notch facing up and toward selector rail.  
Install pin (4).



Coat case rear section in area of reverse gear shaft with Loctite No. 573  
Surface must be thoroughly clean and dried of oil.

Install shaft with needle bearing and reverse gear.




## 23-179

### 23 21 554 REPLACING OUTPUT SHAFT — Output Shaft Removed —

Pull off input shaft (1), brass synchromesh ring (2) and needle bearing (3).

*Note:*  
It is recommended to mark synchromesh rings for a pertinent gear wheel when disassembling the output shaft, in order to avoid mixing up synchromesh rings.




630 23 236

Pull off thrust washer (4), 5th gear (5), brass synchromesh ring (6) and needle bearing (7).



630 23 237

Lift out circlip (8).  
Remove spacer (9).  
*Installation:*  
Always replace circlip.



630 23 238


*Installation:*  
Adjust play between circlip and guide sleeve to 0 ... 0.09 mm (0 to 0.0035").



630 23 239

23 2 080

Press second gear, bearing sleeve, third gear, synchromesh ring and guide sleeve with operating sleeve off of output shaft with Special Tool 23 2 080.  
Pressing-off force\*.




630 23 277

*Version with Thrust Washer:*  
Note thrust washer (2) and ball (3) between 2nd and 3rd gear wheels.




630 23 291

*Important!*  
Snap ring (10) must be removed before pressing off 1st gear.  
*Installation:*  
Always replace snap ring.



630 23 242

Press off 1st gear with guide sleeve and sliding sleeve with Special Tool 23 1 490.  
Remove needle bearing.  
Pressing-off force\*.



23 1 490

630 23 243

\* See Specifications




## 23-181

Install needle bearing, nickel plated synchromesh ring and 2nd gear.

*Important!*

Collar for bearing sleeve on output shaft must protrude slightly.

If applicable, check circlip (10) for correct fit.




630 23 253

Heat bearing sleeve to approx. 80° C (175° F) with a hot air blower and install on output shaft.



630 23 254

Version with Thrust Washer:  
Install ball (3) and thrust washer (2) with opening facing ball (3).




630 23 293

Heat bearing sleeve (4) without collar to approx. 80° C (175° F) with a hot air blower and install on output shaft.



630 23 294



630 23 255

23 1 290

630 23 256

Install needle bearing, 3rd gear and brass synchromesh ring.

Place guide sleeve and operating sleeve on splines with long collar facing 3rd gear.

Since 5.85:

Stepped end of operating sleeve must face the 3rd gear wheel.


Press on guide sleeve to fit tight with Special Tool 23 1 290.

*Important!*

When pressing on parts, make sure that tabs on synchromesh ring are aligned with openings in guide sleeve.

Install spacer and circlip.

# 23-183



Layout Drawing of Gear Set with Bearings:


- 1 Circlip
- 2 Spacer
- 3 Spacer
- 4 Bearing
- 5 Input shaft with 4th gear
- 6 Synchronmesh ring
- 7 Needle bearing
- 8 Circlip
- 9 Spacer
- 10 Drive dog
- 11 Ball
- 12 Spring
- 13 Guide sleeve
- 14 Operating sleeve
- 15 3rd gear
- 16 Needle bearing
- 17 Spacer
- 18 Needle bearing
- 19 2nd gear
- 20 Synchronmesh ring
- 21 Circlip
- 22 Guide sleeve
- 23 Synchronmesh ring
- 24 Operating sleeve
- 25 1st gear
- 26 Needle bearing
- 27 Output shaft
- 28 Reverse gear
- 29 Synchronmesh ring
- 30 Guide sleeve
- 31 Circlip
- 32 Needle bearing
- 33 5th gear
- 34 Bearing
- 35 Spacer
- 36 Spacer
- 37 Speedometer drive gear
- 38 Output flange
- 39 Collar nut
- 40 Lockplate
- 41 Circlip
- 42 Spacer
- 43 Bearing
- 44 Layshaft
- 45 Bearing

30 23 100


## 23-185

Remove selector arm from above.

**Important!**  
Roller.




**Installation:**  
Insert selector arm with Special Tool 23 1 250. Swing out selector arm with roller over locking lever (4).




Position end of spring (3) above high spot. Press (don't knock) down selector arm in this position. Mount selector arm with socket head bolt before removing the special tool. Install socket head bolt with a bolt cement\*\*.

Tightening torque\*.

Remove bearing holder (5).  
**Important!**  
Don't unscrew bolt (6). Locking lever (7) remains on the bearing holder.



**Installation:**  
Check installed position of locking lever (7) and thrust pin (8).




Lift out radial oil seal. Drive out grooved ball bearing with Special Tools 23 1 120 and 00 5 500.

**Important!**  
Shim X.




Determine thickness of shim X. Measure distance (A).




Measure distance (B).

Example:  
A 20.3 mm (0.799")  
B 20.0 mm (0.787")  
X 0.3 mm (0.012") thick shim



\* See Specifications  
\*\* Source of Supply: HWB

23-300



730 23 032


Section Drawing of GETRAG 285/6 Overdrive Manual Transmission

- 1 First gear
- 2 Second gear
- 3 Third gear
- 4 Fourth gear
- 5 Fifth gear
- R Reverse gear
- 6 Input shaft
- 7 Output shaft
- 8 Layshaft

## 23-302


### 23 00 022 REMOVING AND INSTALLING TRANSMISSION

Remove exhaust assembly --- see 18 00 020.  
Unscrew heat shield.




30 23 105

Unscrew joint disc on transmission.  
Always replace stop nuts.



28 23 078

**Installation:**  
Tighten nuts with a standard 19 mm wrench socket and a torque wrench.  
Tightening torque\*.  
**Important!**  
Only tighten nuts on flange end, whenever possible by design, to avoid tension in the joint disc.



28 23 079


Loosen threaded ring (1) several turns.  
**Installation:**  
Tighten threaded ring (1) with Special Tool 26 1 040 after finishing installation.  
Tightening torque\*.



26 1 040


30 23 125

\* See Specifications




30 23 106

Unscrew center mount.  
**Installation:**  
Preload center mount forward by distance (A) = 4 to 6 mm (0.157 to 0.236").  
Bend propeller shaft down and pull it off of centering pin.  
**Important!**  
Don't let propeller shaft fall into the joints.  
Suspend propeller shaft from car on pieces of wire.




30 23 138

Lift out retainer (2).  
Note washers (3 and 4).  
Pull out shift rod.



30 23 137


Unscrew holder for shift arm on transmission.




28 23 087

Pull off wires on reverse gear switch.  
Unscrew clutch slave cylinder --- pipe remains connected.  
**Installation:**  
Bleeder screw faces down.

## 23-304




**23 00 032 INSTALLING EXCHANGE TRANSMISSION**  
Remove transmission – see 23 00 022.  
BMW code\* marked on intermediate case section.



Transfer shift rod joint.  
Push back locking sleeve (1).  
Drive out cylindrical pin (2).



Transfer spring (1) and release lever (2) with release (3).



316 23 025

**Installation:**  
Pack lubricating groove (N) with Molykote Longterm 2.  
Give guides (F) and bearings (L) a light coat of Molykote Longterm 2.  
Non-conformance could cause bearing to seize on the guide sleeve.


Transfer rubber mounts with cross member, exhaust carrier and backup light switch.

**Note:**  
Transmissions are supplied filled with oil, so that it is only necessary to check the oil level after installation of the transmission.


## 23-306




Coat sealing surfaces with Loctite No. 573. Sealing surfaces must be cleaned thoroughly and dried of oil. Mount front transmission case section. Tightening torque\*.



Install lockpin and backup light switch. Note arrangement of lockpin.



Adjust play between washer (4) and circlip (3) to 0 ... 0.09 mm (0 to 0.0035"). Circlips (3) are available from Parts in various thicknesses. Install grooved washer and circlip.




Heat ball bearing inner race (8) to about 80° C (175° F) with a hot air blower and slide on to input shaft. Pull out input shaft for this purpose.

\* See Specifications

## 23-308

Knock out end cap (4).


**Installation:**  
Replace and install end cap with Loctite No. 573.



730 23 176


Position output shaft upright.

Second gear is engaged.  
Adjust reverse/5th gear selector rod until opening of 5th gear selector rod is aligned with end of 1st/2nd gear selector rod.




730 23 064

Coat sealing surfaces with Loctite No. 573.  
Sealing surfaces must be cleaned thoroughly and dried of oil.  
**Important!**  
Lockpin (6) must move easily and face down.




730 23 065

Hold rollers in position with grease.  
Mount transmission case rear section.  
Make sure spring (7) of selector arm engages on lever (8).




730 23 056




730 23 067

Press lockpin (6) into opening of 1st/2nd gear selector rod.  
Push on and bolt down transmission case rear section.  
Tightening torque\*  
Drive in centering pin.  
Install end cap (4).




730 23 068

Heat bearing inner race (9) to about 80° C (175° F) with a hot air blower and slide on to output shaft, if necessary knocking on against ball bearing with Special Tool 23 1 440.



730 23 177

Install spacer (2).



730 23 178

Drive in radial oil seal flush with Special Tool 23 1 370.


\* See Specifications



## 23-310


### 23 11 610 REPLACING CLUTCH RELEASE GUIDE TUBE — Transmission Removed —

Remove guide flange — see 23 11 623.  
Press out guide tube.



730 23 166

Heat guide flange to about 80° C (175° F) with a hot air blower.  
Install guide tube.  
**Note:**  
Check turning lock (1).  
Install radial oil seal.



730 23 167

### 23 11 623 REMOVING AND INSTALLING OR SEALING COVER WITH GUIDE TUBE FOR CLUTCH RELEASE

Unscrew cover.

**Important!**

Spacers.


**Important! — Installation:**

Check length of bolts.

Bolts (1 ... 3) = 8 x 30 mm


Bolts (4, ... 7) = 8 x 22 mm

Adjust ball bearing between input shaft and guide flange to 0 ... 0,09 mm (0 to 0,0035"). Measure distance (A) from case to ball bearing.



730 23 169

Measure distance (B).  
Example:  
B 8.1 mm (0.319")  
— A 7.8 mm (0.307")  
0.3 mm (0.012") spacer thickness




730 23 170

Adjust roller bearing play between layshaft and guide flange.  
Measure distance (C) from case to roller bearing outer race.



730 23 171

Measure distance (D).  
Example:  
D 4.8 mm (0.189")  
— C 4.3 mm (0.169")  
0.5 mm (0.020")  
— 0.1 ... 0.2 mm (0.004 ... 0.008") axial play  
0.3 mm (0.012") spacer thickness



730 23 172

Coat sealing surfaces with Loctite No. 573.  
Sealing surfaces must be cleaned thoroughly and dried of oil.  
Hold spacers of calculated thickness in position with grease.  
Mount cover.  
Install bolts with Loctite No. 573.  
Tightening torque\*  
Threads cleaned to remove old cement.


730 23 173

\* See Specifications


## 23-312

### 23 12 083 REPLACING RADIAL OIL SEAL SELECTOR SHAFT


Unscrew propeller shaft — see 23 00 022.  
Unscrew input flange — see 23 12 053.  
Holder (1) must be taken off of the transmission partially, in order to be able to drive out the cylindrical pin for the selector rod joint.




Engage 3rd gear.  
Push locking sleeve (1) away and drive out cylindrical pin (2).



Lift out radial oil seal.




Lubricate sealing lip of radial oil seal with oil.  
Drive in radial oil seal with Special Tool 23 1 240.




### 23 12 503 REPLACING RADIAL OIL SEAL FOR INPUT SHAFT — Transmission Removed —


Remove cover with guide tube — see 23 11 623.  
Lift out radial oil seal.




Drive in radial oil seal against stop with Special Tools 23 1 180 and 00 5 500.  
Open end faces transmission.  
Lubricate sealing lip with oil.




## 23-314




Pull or take off turning lock (5) and reversing lever (6).  
Pull out selector rail (7) forward.  
Disengage second gear.



Pull out 5th gear selector rod with selector fork and operating sleeve toward rear far enough, that pin (8) can be driven out while counterholding.  
*Important!*  
Loose balls, springs and slides.  
*Installation:*  
Replace pin.




Pull off operating sleeve and fifth gear selector fork.  
Pull out selector rod (9) forward.  
*Important!*  
Loose balls.




Pull guide sleeve and bearing inner race off of output shaft with Special Tools 23 1 420 and 33 1 301.  
*Important!*  
Hold knurled head bolts in recesses of guide sleeve with a pliers.



Take off synchromesh ring.  
Pull off reverse gear and needle bearing.




Engage third gear.  
Drive out pin (10).  
*Important!*  
Drive in pin on to tooth of 3rd gear wheel until selector rod can be pulled out forward.  
Remove 3rd/4th gear selector fork.  
Loose balls.  
*Installation:*  
Replace pin.



Pull out output shaft toward rear far enough, that bearing inner race can be pulled off with Special Tools 23 1 060 and 33 1 301.


Remove shim X.  
*Installation:*  
Determine thickness of shim X (see 23 21 554).

## 23-316




Drive pin out of 1st/2nd gear selector rod.  
*Installation:*  
 Replace pin.


Mount 1st/2nd gear selector fork.  
 Push in 1st/2nd gear selector rod up to spring.  
 Insert locking balls and press down.  
 Push in selector rod against arrest in this position.




Drive in 6 x 32 mm pin, while counterholding.




Mount 3rd/4th gear selector fork.  
 Insert detent ball.  
 Push in selector rod up to spring.  
 Insert locking balls and press down.  
 Push in selector rod against arrest in this position.



Drive in 6 x 26 mm pin, while counterholding.




Assemble synchronizer.  
 Installed Order:  
 Springs (2), thrust parts (3) and balls (4).  
 Curved surface of thrust parts (3) faces operating sleeve.



Layout of Selector Arrest:

- 1 Locking ball
- 2 Spring
- 3 Detent ball



730 23 035

## 23-318

Hold four rollers in position on selector shaft with grease.



Heat bearing inner race to approx. 80° C (175° F) with a hot air blower and install on layshaft.  
If necessary, drive on with Special Tool 23 1 030.  
Collar of bearing race faces gear.


Insert ball (2) with grease.  
Push on washer (1).



**Installation:**  
Heat ball bearing inner races to approx. 80° C (175° F) with a hot air blower and install on output shaft.  
**Important!**  
Turning lock.  
Opening in bearing inner race must engage in ball.  
Draw line (1) to make installation of bearing race easier.


Install selector shaft, while pushing on selector arm (3) with long finger facing 3rd/4th gear selector rod.

**Important!**  
Arrest on selector shaft faces selector rail (4).  
Drive in 6 x 32 mm pin, while counterholding.



730 23 113


# 23-320




730 23 006

- 1 Ball bearing
- 2 Input shaft with 4th gear
- 3 Turning lock
- 4 Needle bearing
- 5 Synchronmesh ring
- 6 Snap ring
- 7 Washer
- 8 Thrust part
- 9 Ball
- 10 Spring
- 11 Guide sleeve
- 12 Sliding sleeve
- 13 3rd gear
- 14 Needle bearing
- 15 Bearing sleeve
- 16 Output shaft
- 17 Ball
- 18 2nd gear
- 19 1st gear
- 20 Bearing race
- 21 Roller bearing
- 22 Shim X
- 23 Reverse gear
- 24 Circlip
- 25 Bearing sleeve
- 26 Split needle bearing
- 27 5th gear
- 28 Washer
- 29 Ball bearing
- 30 Washer
- 31 Speedometer drive gear
- 32 Radial oil seal
- 33 Output flange
- 34 Collar nut
- 35 Lockplate
- 36 Roller bearing
- 37 4th gear
- 38 Circlip
- 39 3rd gear
- 40 Layshaft
- 41 Roller bearing
- 42 5th gear
- 43 Roller bearing
- 44 Bolt
- 45 Washer
- 46 Washer
- 47 Thrust washer
- 48 Needle bearing
- 49 Reverse gear
- 50 Bearing shaft
- 51 Bearing holder


## 23-322




Drive out ball bearing with Special Tools 00 5 500 and 23 1 080.




Drive in ball bearing with Special Tools 23 1 410 and 00 5 500.



Adjust play between bearing holder and case rear section with shims. Mount bearing holder. Tightening torque\*.




Pull ball bearing inner race off of output shaft with Special Tools 23 1 100 and 00 7 500.




**Installation:**  
Heat ball bearing inner race to approx. 80° C (175° F) with a hot air blower and slide on to output shaft.

**Important!**  
Opening in bearing inner race must engage in ball.  
Draw line (1) to make installation of bearing race easier.




Heat case rear section to approx. 80° C (175° F) with a hot air blower.  
Lift out roller bearing (2).

**Installation:**  
Insert bearing that large diameter end of plastic cage faces up.



Heat case rear section to approx. 80° C (175° F) with a hot air blower.  
Install roller bearing, driving in with Special Tools 23 1 390 and 00 5 500.



Bearing inner race (3) can only be pulled off together with the 5th gear — see 23 21 503.

\* See Specifications

# 23-324

## 23 23 505 DISASSEMBLING AND ASSEMBLING COMPLETE SYNCHRONIZATION — Output Shaft Removed —




630 23 077

Disassemble output shaft — see 23 21 554.  
All synchronesh rings are identical and coated with molybdenum on the inside.  
Check distance\* between synchronesh ring and clutch.  
Measure in area of stops.  
Synchronesh rings should bear uniformly all around.



635 23 137

Disassemble synchronization.  
Pressure piece (1)  
Spring (2)  
Ball (3)  
*Installation:*  
Bore (4) in operating sleeve must be aligned with ball (3).



630 23 079

*Installation:*  
Install all springs, pressure pieces and balls.  
*Important!*  
Curved surface of pressure pieces faces the operating sleeve.  
Install guide sleeve that half of it is in the operating sleeve.  
Press in balls far enough until the guide sleeve can be pressed into the operating sleeve.

\* See Specifications



# 24 Automatic Transmission

3 HP - 22		
24 00 004	Selector lever, throttle control and throttle cable — adjust .....	24 - 4
009	Hydraulic pressure valves — check .....	24 - 6
020	Transmission — remove and install .....	24 - 7
040	Exchange transmission — install .....	24 - 8
080	Transmission — disassemble and assemble .....	24 - 9
24 11 000	Oil sump — remove and install .....	24 - 14
050	Transmission extension — remove and install/seal .....	24 - 14
24 12 001	Radial oil seal for torque converter — replace .....	24 - 16
011	Radial oil seal for output flange — replace .....	24 - 16
101	Radial oil seal for manual shift valve shaft — replace .....	24 - 17
24 23 020	Multiple plate clutches and brakes — replace .....	24 - 18
24 30 000	Valve body — remove and install .....	24 - 22
24 31 000	Primary pump — remove and install .....	24 - 23
150	Transmission oil filter screen — remove and install .....	24 - 24
24 32 000	Centrifugal governor — remove and install .....	24 - 24
503	Centrifugal governor — disassemble and assemble .....	24 - 24

# 24 Automatic Transmission

4 HP - 22

Layout drawing .....	24-101
Power flow diagrams .....	24-102
Transmission diagram / shift components .....	24-103
Selector lever, throttle linkage and throttle cable - adjust .....	24-104
24 00 006 Hydraulic pressure values - check .....	24-106
011 Transmission - remove and install .....	24-107
022 Transmission - exchange .....	24-110
042 Transmission - disassemble and assemble .....	24-111
082 Oil sump - remove and install .....	24-119
24 11 002 Transmission extension - remove and install / seal .....	24-120
052 Radial oil seal for torque converter - replace .....	24-121
24 12 003 Radial oil seal for output flange - replace .....	24-121
013 Radial oil seal for manual shift valve shaft - replace .....	24-122
103 Transfer plate for automatic transmission - replace .....	24-123

# 24 Automatic Transmission

4 HP - 22	
Automatic transmission 4 HP - 22 / H - troubleshoot .....	24 - 149
Automatic transmission 4 HP - 22 / EH - troubleshoot .....	24 - 151
Valve body 4 HP - 22 / EH - troubleshoot .....	24 - 158
Shift layout drawing AEGS .....	24 - 161
Plug connections .....	24 - 162
AEGS test plan .....	24 - 164

# 24-1


Power Flow Diagrams 3 HP - 22

**1st Gear**  
Clutch A is engaged. Planet gear carrier bears on one-way clutch F during acceleration and is cancelled while coasting. With the selector lever in position 1 clutch D is also engaged when in 1st gear, to be able to utilize the engine's braking force.

**2nd Gear**  
Clutches A, C' and C are engaged. One-way clutch F is cancelled. The hollow shaft is fixed with the sun gear.

**3rd Gear**  
Clutches A, B and C are engaged. One-way clutches E and F are cancelled. The entire planet gear set turns as a single unit at a ratio of 1 : 1.


**Reverse Gear**  
Clutches B and D are engaged. The output shaft's direction of rotation is reversed by the held planet gear carrier. The power flow 1st, 2nd, 3rd and reverse gears is via the hold parts.



316 24 010

3 HP - 22 Transmission Layout

- 1 Input
- 2 Torque converter
- 3 Planet gear set
- 4 Output



530 24 010

## Explanation of Hydraulic Valve Body

The main pressure valve controls the pressure level in the hydraulic valve body. As soon as the valve body is filled with oil, the supply of oil to the torque converter is released. If the delivery rate increases, any excessive oil is returned to the primary pump via the intake port.

The converter pressure valve has been given the task of preventing excessive pressure in the torque converter.

The selector slide valve is operated mechanically by the selector lever. The valve directs the oil pressure in the valve body to the desired driving ranges.

The governor determines, in conjunction with the shift valves the shift points depending on the throttle pressure. The governor pressure is produced in accordance with the input shaft's speed.


There will be no upshifts or downshifts when the governor piston and/or governor bush seize due to dirt.  
Clean governor (see 24 32 503).



The throttle pressure valve is connected with the accelerator cable and determines with the governor the shift points depending on the throttle valve position.

The locking valves have the task of initiating the downshifts into the different gears regardless of the throttle valve position. Further the locking valves will prevent the other gears from engaging automatically when the selector lever is positioned at 1 or 2.

The shift valves determine which gear is engaged. If the spring pressure in a shift valve is overcome by governor pressure, the oil pressure goes to the clutch valves and shuts the pertinent clutches. When Kickdown is operated, the spring pressure receives more support from the throttle pressure. Because of this the engine speed must pick up, so that governor pressure can overcome the spring force and throttle pressure.

The clutch valves and dampers are meant to make gear shifts as smooth as possible.





- B) Adjusting Throttle Cable:  
Requirement: full throttle setting correct.  
Adjust play (S) to  $0.50 \pm 0.25$  mm ( $0.020 \pm 0.010$ ") with nuts (1) in neutral position.  
Check kickdown stop (2).  
Unscrew lock nut (3) and screw in kickdown stop (2).  
Depress accelerator pedal (4) to transmission's pressure point.  
Unscrew kickdown stop in this position until accelerator pedal touches.  
Depress accelerator pedal (4) to kickdown (final position).  
Distance (S) from lead seal (5) to end of sleeve (6) should now be at least 44 mm (1.732").

## 24-7

### 24 00 020 REMOVING AND INSTALLING TRANSMISSION

Disconnect battery ground lead.

Unscrew nut (1).

Disconnect throttle cable.

*Installation:*  
Adjust throttle cable (see 24 00 004).



30 24 007

Remove exhaust assembly 18 00 020.  
Unscrew heat shield.




30 24 009

Unscrew joint disc on transmission.  
Disconnect selector rod (2).

*Installation:*

Tighten bolts to correct torque\*.

Adjust selector lever 24 00 004.



20 24 002

Loosen threaded ring (1) several turns.

*Installation:*

Tighten threaded ring (1) with Special T tool

26 1 040 after finishing installation.


Tightening torque\*.



26 1 040

30 23 125

\* See Specifications



30 23 106

Unscrew center mount.

*Installation:*  
Preload center mount forward by distance A =

2 to 4 mm (0.079 to 0.157").

Tightening torque\*.

Bend propeller shaft down and pull it off of

centering pin.

*Important!*

Suspend propeller shaft from car on piece of wire.



30 24 010

Drain oil.

*Important!*

Never reuse drained oil.

*Installation:*  
If oil smells burnt and is black, the transmission

will have to be disassembled.

*Important!*

If transmission is defective, clean oil cooler and lines with compressed air and flush twice with ATF.

Remove oil filler tube.

Disconnect oil cooler line on transmission.



30 24 017

Remove reinforcement plate.


*Installation:*

Tightening torque\*.

Unscrew torque converter at four points on drive plate while cranking engine on vibration damper.

*Installation:*


Tightening torque\*.



30 24 011

\* See Specifications

## 24 - 9




24 0 150

316 24 039

### 24 00 080 DISASSEMBLING/ASSEMBLING TRANSMISSION


Remove transmission 24 00 020.  
Remove torque converter 24 40 000.  
Mount transmission on Special Tool 24 0 150 in conjunction with an assembly stand.  
*Caution!*  
Screw in bolts only finger tight to avoid transmission case distortion.

a) Disassembling:  
Detach oil sump.




316 24 040

Remove valve body.  
Unscrew Torx bolts with Special Tool 00 2 100.




28 24 027

Remove circlips.  
Remove springs (3 ... 6).




316 24 042



24 2 050

316 24 013

Pull out dowel sleeves with Special Tool 24 2 050.




23 1 200

23 1 210

316 24 044


Engage parking lock.  
Apply Special Tool 23 1 200.  
Unscrew collar nut with Special Tool 23 1 210.  
Pull off output flange.

Disconnect exhaust support.  
Detach transmission extension.



316 24 045

Loosen nut (7) and unscrew stud (8) about 3 turns.  
Pull off governor.



316 24 016



## 24-11



316 24 056

Pull centering plate (1) and clutch set (2) with clutches C, C and D off of output shaft (3).

Remove planet gear set with sun gear shaft.

*Important!*


Needle bearing (22) and thrust washer (23).



316 24 057

b) Assembling:  
Detach governor flange.

Replace gasket (1).  
Tightening torque\*.




316 24 058

Install angled washer (2) with grease that angled surface is on output shaft.  
Install needle bearing and thrust washer on the output shaft.



316 24 059


\* See Specifications



316 24 060


*Important!*  
Woodruff keys must be in center of groove of cylinder.  
Parking lock must not be engaged.  
Guide complete output set into transmission case that the 4 oil bores in the output set are aligned with bores in the bottom of the transmission case.

Install snap ring (5).




316 24 061

Install clutch B.



316 24 062


Install seal (6) and press in against stop with support (7).  
Install snap ring (8).



316 24 063

## 24 - 13

Press in four dowel sleeves against stop with a suitable mandrel.





Install and lock springs. Both short springs (1 and 2) are located on the selector lever side.




Install valve body that clamp on selector valve can be engaged in operating finger of pawl. Tighten transmission cables slightly for this purpose, so that throttle cams cannot clamp with the throttle pressure valve.


Screw in valve body bolts finger tight.



Align valve body with Special Tool 24 3 050. If special tool gage is not available, make sure distance from valve body case to pin in throttle pressure piston is 11.5 mm (0.453"). Mount valve body.




Tighten torx bolts with Special Tools 00 2 100 and 00 2 050. Tightening torque\*.




Mount gasket on oil sump. Install magnets. Check installed position.

Bolt oil sump with brackets. Short leg of bracket presses down on oil sump. Tightening torque\*.



\* See Specifications

## 24-15




Remove lockplate.

*Installation:*  
Lock lockplate in output flange groove.




Engage parking lock.  
Apply Special Tool 23 1 200.  
Unscrew\* collar nut with Special Tool 23 1 210.  
Pull off output flange.


*Installation:*  
Install collar nut with Curil K 2 or Hylomar SQ 32 M\*\*.



Support transmission with Special Tools 23 0 000 and 00 2 020.  
Remove cross member.  
Lower transmission.  
Detach transmission extension.




Loosen nut (4) and unscrew stud (5) about 3 turns.  
Pull off governor.



*Installation:*  
Compress piston rings lightly and push governor on to governor flange.

*Important!*  
Punch mark (1) on output shaft must be aligned with opening (2) in governor flange.  
Bolt governor.



Detach bearing flange.

*Important!*  
Angled washer (5), thrust washer (6) and needle bearing (7).  
Replace gasket (8).  
Tightening torque\*.


\* See Specifications for tightening torque  
\*\* Source: HWB

\* See Specifications

## 24-17

24 12 101 REPLACING RADIAL OIL SEAL  
FOR MANUAL SHIFT VALVE  
SHAFT

Detach selector lever (1) on transmission.




316 24 093

Remove radial oil seal (2).

*Installation:*  
Lubricate sealing lip with oil.  
Drive in radial oil seal flush.

## 24-19

**Clutch B:**  
Remove snap ring (1).  
Remove outer and lined plates.




24 2 030

316 24 097

Bend open lockwasher (2).  
Press down on diaphragm spring with Special Tool 24 2 030 and lift out snap ring (3).

**Installation:**  
Replace lockwasher.  
Install diaphragm spring with curved surface facing up.



28 24 034

Press out piston for clutch B with compressed air applied through oil bore.




28 24 013

**Installation:**  
Check O-rings (4 and 5), replacing if necessary.



28 24 014



316 24 098

**Installed Order:**

- 1 Outer plates 1.8 mm —three
- 2 Lined plates — three
- 3 End plate 4.5 mm — one

**Important!**  
Install end plate with ground side facing lined plate.

4 Housing


**Clutch C:**  
To facilitate operations place entire set in a pipe with an inside diameter of 29 mm (1.142") and clamp in a vise.  
Lift off centering plate (5).  
Remove outer lined plate and one-way clutch.



316 24 099

Press down on diaphragm spring with Special Tool 24 2 030 and remove split retainer (1).


**Installation:**  
Insert diaphragm spring with curved surface facing up.



28 24 015

Press out piston for clutch C' with compressed air applied through oil bore.

**Installation:**  
Check O-rings (2 and 3), replacing if necessary.




28 24 016

## 24-21

Press out piston for clutch D with compressed air applied through oil bore.

*Installation:*  
Check O-rings (3 and 4), replacing if necessary.



2E 24 020

Remove plates.

Installed Order:

2 Outer plates 1.8 mm

3 Lined plates

4 End plate 4.5 mm

*Important!*


Insert end plate with ground side facing lined plate.

316 24 105

## 24-23


### 24 31 000 REMOVING AND INSTALLING PRIMARY PUMP

Remove torque converter 24 40 000.  
Detach converter bell housing with transfer plate.




316 24 109

*Installation:*  
Install angled washer (1) on input shaft with collar facing needle bearing (2).  
Install thrust washer (3) on converter bell housing with grease.  
Replace gasket (4).




316 24 110

Detach transfer plate on converter bell housing.  
Loosen tow bolts opposite each other by only several turns.  
Loosen primary pump on converter bell housing by applying light knocks.  
Unscrew bolts and take off primary pump.




316 24 111

*Installation:*  
Lift off transfer plate (5).  
Replace gasket (6).  
Tightening torque\*.




316 24 112

\* See Specifications




28 24 022

*Installation:*  
A primary pump, consisting of pump body (7), hollow gear (8) and impeller (9), may only be replaced as a complete part.  
Check O-ring (10), replacing if necessary.  
Install hollow gear (8) and impeller (9) that punch marks face up.



316 24 114

Measure axial play\* between both gears and face surface with a depth micrometer.



316 24 115

Check primary pump for easy running with Special Tool 24 3 140.  
Repeat this test after installation of the transfer plate.



24 3 140


316 24 116

\* See Specifications

## 24-25

### 24 34 000 REMOVING AND INSTALLING PARKING LOCK PAWL

- Remove valve body 24 30 000.
- Remove transmission extension 24 11 050.
- Remove circlip (1).
- Take off washer (2).
- Disconnect spring (3) and pull off parking lock cam (4).
- Disconnect spring (5) and push out pin (6) from inside to outside, or pull out.



316 24 121

**Installation:**  
 Press in pin, sliding spring (5) and pawl (7) on to pin.  
 Straight leg of spring faces up on transmission case.  
 Front leg of spring is located behind pawl on left side.




316 24 122

Connect front end of spring on right side of pawl.

### 24 34 100 REPLACING THROTTLE CABLE


- Unscrew nut (1).
- Disconnect throttle cable.



316 24 123


30 24 007

- Detach oil sump 24 11 000.
- Move selector lever to N.
- Push throttle cam forward and disconnect throttle cam cable.




316 24 124

Push throttle cable out of case upwards.



316 24 125

Press new throttle cable into case until retaining tabs engage.  
 Connect nipple on throttle cam.  
 Insert Special Tool 24 3 050 between valve body case and throttle pressure valve.  
 Press throttle cam against throttle pressure valve.



24 3 050

316 24 108

Connect throttle cable in suspension on transmission and holder.  
 Tighten cable.  
 Squeeze loose seal on cable at distance (A) of 0.25 to 0.50 mm (0.010 to 0.020").  
 Adjust throttle cable 24 00 004.



30 24 012



## 24-27

### 24 40 000 REMOVING AND INSTALLING TORQUE CONVERTER

Remove and install transmission 24 00 020. Pull torque converter out of primary pump carefully with Special Tools 24 4 000.


*Important!*  
Escaping ATF!



316 24 133

*Installation:*  
Check torque converter for leaks with Special Tools 24 4 041, 24 4 043 and 24 4 062. Test pressure: 0.5 bar (7 psi).

*Important!*  
Always use Special Tool 24 4 043 to prevent injury.




316 24 134

Torque converter must be replaced when bearing surface on converter shaft is damaged.




316 24 135

Torque converter must be replaced when stator (L) or turbine (T) cannot be turned by hand.




316 24 136



30 24 001

Turn slightly to guide openings on converter into primary pump carefully, using Special Tool 24 4 000.

*Important!*  
Be careful not to damage converter bearings and seal while guiding in.



30 24 015

### 24 40 001 REPLACING TORQUE CONVERTER

Check torque converter installed in car. Engine and transmission oil must have operating temperature.

Engine must produce full rated power.

Start engine.

Pull on parking brake and operate brake pedal firmly.

Move selector lever to R or 1 and press accelerator pedal to full throttle.

Read stall speed\* from tachometer.

*Important!*

Never test stall speed longer than 10 seconds to prevent damage from excessive heat.

Stall Speed Much Above Specified Value\*.

a) Converter oil volume insufficient —

correct oil level.

b) Slip in clutches — check clutches.

Stall Speed Much Below Specified Value\*.

a) Engine power insufficient — check engine.

b) Converter or pump defective — replace converter or check pump.

Torque converters cannot be cleaned with conventional workshop equipment and must be replaced when a transmission had been defective or an oil filter screen torn.  
Converter identification\*.



316 24 143

\* See Specifications

## 24-30

### TROUBLESHOOTING AUTOMATIC TRANSMISSION 3 HP - 22


Condition	Cause	Correction
Slipping or shaking when moving off in reverse gear	<ul style="list-style-type: none"> <li>a) Clutch B or D damaged</li> <li>b) Strong leak in feed line to B or D</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace clutches B and D 24 23 020</li> <li>b) Disassemble transmission 24 00 080</li> </ul>
No drive in reverse and 2nd gear	<ul style="list-style-type: none"> <li>a) Shift valve seized in 3rd gear position</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace valve body 24 30 000 and disassemble transmission if oil pan has abrasion</li> </ul>
Hard engaging jolt or definite double knock when engaging reverse gear	<ul style="list-style-type: none"> <li>a) Damper B defective or wrong plate</li> <li>b) Accelerator cable maladjusted</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace valve body 24 30 000</li> <li>b) Adjust accelerator cable 24 00 004</li> </ul>
Car cannot be started in N or P	<ul style="list-style-type: none"> <li>a) Transmission switch defective</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace transmission switch 61 31 260</li> </ul>
Car creeps or moves in N	<ul style="list-style-type: none"> <li>a) Selector linkage maladjusted</li> <li>b) Clutch A discharges too slowly</li> <li>c) Clutch A defective (bonded)</li> </ul>	<ul style="list-style-type: none"> <li>a) Selector linkage adjustment 24 00 004</li> <li>b) Disassemble transmission 24 00 080</li> <li>c) Disassemble transmission 24 00 080</li> </ul>
No power flow in D or R	<ul style="list-style-type: none"> <li>a) Oil filter screen clogged</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace oil filter screen 24 31 150</li> </ul>
Drive only in reverse gear	<ul style="list-style-type: none"> <li>a) Clutch A defective</li> <li>b) One-way clutch for 1st gear slips</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace clutch A 24 23 020</li> <li>b) Disassemble transmission 24 00 080</li> </ul>
Drive only in 1st gear when in D	<ul style="list-style-type: none"> <li>a) Shift valve 1-2 seized</li> <li>b) Governor bushing seized</li> </ul>	<ul style="list-style-type: none"> <li>a) Clean or replace governor 24 32 000</li> </ul>
Drive only in 1st and 2nd gears when in D	<ul style="list-style-type: none"> <li>a) Shift valve 2-3 seized</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace valve body 24 30 000</li> </ul>
Drive only in 2nd gear	<ul style="list-style-type: none"> <li>a) Shift valves 1-2 and 2-3 seized</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace valve body 24 30 000</li> </ul>
Drive only in 3rd gear	<ul style="list-style-type: none"> <li>a) Shift valves 1-2 and 2-3 seized</li> <li>b) Governor bushing seized</li> </ul>	<ul style="list-style-type: none"> <li>a) Clean or replace governor 24 32 000</li> </ul>
Drive in "N"	<ul style="list-style-type: none"> <li>a) Selector linkage maladjusted or disconnected</li> <li>b) Clutch A (forward) bonded</li> <li>c) Clutch B (reverse) bonded</li> </ul>	<ul style="list-style-type: none"> <li>a) Adjust or connect selector linkage 24 00 004</li> <li>b) Disassemble transmission 24 00 080</li> <li>c) Disassemble transmission 24 00 080</li> </ul>
No braking effect from 1st gear in 2 or 1	<ul style="list-style-type: none"> <li>a) Clutch valve and damper D defective</li> <li>b) Clutch D defective</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace valve body 24 30 000</li> <li>b) Clutch D replacement 24 23 020</li> </ul>
No braking effect from 2nd gear in 2 or 1	<ul style="list-style-type: none"> <li>a) Clutch C defective</li> <li>b) Circlip C + C' broken (if applicable)</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace clutch C 24 23 020</li> <li>b) Replace circlip 24 23 020</li> </ul>
No reverse gear (forward positions okay)	<ul style="list-style-type: none"> <li>a) Selector linkage maladjusted</li> <li>b) Oil level too low</li> <li>c) Clutch B or D defective</li> </ul>	<ul style="list-style-type: none"> <li>a) Adjust selector linkage 24 00 004</li> <li>b) Correct oil level</li> <li>c) Replace clutches B and D 24 23 020</li> </ul>

## 24-32

### TROUBLESHOOTING AUTOMATIC TRANSMISSION 3 HP - 22

Condition	Cause	Correction
Howl, depending on speed and load	<ul style="list-style-type: none"> <li>a) Center mount of propeller shaft defective</li> <li>b) Needle bearing in transmission extension defective</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace center mount 26 11 501</li> <li>b) Replace needle bearing 24 11 050</li> </ul>
Rattling noise in idle	<ul style="list-style-type: none"> <li>a) Drive plate broken</li> <li>b) Welded tabs on converter torn off</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace drive plate 11 22 051</li> <li>b) Replace converter 24 40 000</li> </ul>
Grinding noise in idle which disappears when accelerating in position N	<ul style="list-style-type: none"> <li>a) Valves rattling in valve body</li> <li>b) Oil pump drawing in air</li> </ul>	<ul style="list-style-type: none"> <li>a) Tighten * valve body mounting bolts</li> <li>b) Check tightness of valve body, tightening torque*</li> </ul>
High pitch noise in all positions, especially when oil is cold	<ul style="list-style-type: none"> <li>a) Intake noise of oil pump,</li> <li>b) Intake noise on valve body</li> </ul>	<ul style="list-style-type: none"> <li>a) Check oil level</li> <li>b) Replace valve body 24 30 000</li> <li>c) Replace oil filter screen 24 31 150 and disassemble transmission when oil is contaminated</li> </ul>
Scratching or screeching noise in all positions, especially when oil is warm, occurring after long drive	<ul style="list-style-type: none"> <li>a) Oil level too low</li> <li>b) Intake noise on valve body</li> <li>c) Oil filter screen dirty</li> </ul>	<ul style="list-style-type: none"> <li>a) Correct oil level</li> <li>b) Replace valve body 24 30 000</li> <li>c) Replace oil filter screen 24 31 150 and disassemble transmission when oil is contaminated</li> </ul>
Oil on converter bell housing	<ul style="list-style-type: none"> <li>a) Shaft seal defective</li> <li>b) O-ring on primary pump housing defective or mounted incorrectly</li> <li>c) Converter leaking at welded seams</li> <li>d) Plug leaks</li> <li>e) O-ring on accelerator cable defective</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace shaft seal 24 12 001</li> <li>b) Replace O-ring 24 31 000</li> <li>c) Replace converter 24 40 000</li> <li>d) Replace seal</li> <li>e) Replace O-ring or accelerator cable 24 34 100</li> </ul>
Oil on output flange	<ul style="list-style-type: none"> <li>a) Shaft seal defective</li> <li>b) Output flange leaks at threads</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace shaft seal 24 12 011</li> <li>b) Install collar nut with Curil K 2 or Hylomar SQ 32</li> </ul>
Vent leaks	<ul style="list-style-type: none"> <li>a) Oil level too high</li> <li>b) Wrong oil (strong foaming)</li> <li>c) Vent defective</li> <li>d) Vent mounted incorrectly</li> <li>e) O-ring on vent leaks</li> <li>f) Lockwasher preload excessive</li> </ul>	<ul style="list-style-type: none"> <li>a) Correct oil level</li> <li>b) Replace oil</li> <li>c) Replace vent</li> <li>d) Remove transmission extension and insert vent correctly (opening faces left looking forward) 24 11 050</li> <li>e) Replace O-ring</li> <li>f) Replace lockwasher 24 11 050</li> </ul>
Oil on speedometer drive	<ul style="list-style-type: none"> <li>a) O-ring defective</li> <li>b) Seal in speedometer bushing defective</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace O-ring</li> <li>b) Replace speedometer bushing</li> </ul>

\* See Specifications



733 24 063

ZF 4 HP 22 Layout Drawing

- 1 Input
- 2 Converter lockup clutch
- 3 Hydrodynamic torque converter
- P = Impeller
- R = Stator
- T = Turbine

- 4 Clutch A
- 5 Clutch B
- 6 Clutch C
- 7 Clutch C
- 8 Clutch D


- 9 Planet gear set
- 10 Planet gear set - 4th gear
- 11 Clutch E
- 12 Clutch F
- 13 Output

- 14 One-way clutch
- 15 One-way clutch
- 16 One-way clutch
- 17 One-way clutch




# 24-104 a

Engine M 10:



Engine M 20:

- B) Adjusting Throttle Cable:  
Requirement: full throttle adjustment correct.  
Adjust play (S) to  $0.50 \pm 0.25$  mm ( $0.020 \pm 0.010$ "') with nuts (1) in idle position.  
Check kickdown stop (2).  
Loosen lock nut (3) and screw in kickdown stop (2).  
Push down accelerator pedal (4) to transmission pressure point.  
Unscrew kickdown stop in this position, until it contacts the accelerator pedal.  
Push down accelerator pedal (4) to kickdown (final position).  
Now distance (S) from lead seal (5) to end of sleeve (6) must be at least 44 mm (1.732").



## 24-106

### 24 00 011 CHECKING HYDRAULIC PRESSURE VALUES

Connect hose 24 0 021 with pressure tester 13 3 061.




- Remove pertinent plugs for testing.
- 1 Pump pressure
  - 2 Clutch A
  - 3 Converter pressure
- Installation:  
Tightening torque\*.




- A) Pump Pressure:  
Install adapter 24 0 070 with seal on transmission.  
Connect elbow pipe 24 0 023 in conjunction with hose 24 0 021.

- B) Converter Pressure:  
Install adapter 24 0 030 on transmission.  
Connect elbow pipe 24 0 023 in conjunction with hose 24 0 021.



\* See Specifications

Test:		Pos.	Gear	Speed (rpm)	Pressure in bar (psi)
Pump pressure	D	1st	700 ... 1000	6.0 ... 7.5 (86 ... 106)	
	R	2nd/3rd/4th	approx. 4000	4.6 ... 5.8 (66 ... 82)	
Converter pressure	D	reverse	700 ... 1000	1.1 ... 1.3 (15.7 ... 18.4)	
	D	4th	converter locked	max. 0.7 (10)	



Correct oil level with selector lever in P.  
Transmission having operating temperature and engine running at idle speed.  
Park car on level floor or ground.  
Oil level of transmission having operating temperature should be between both marks.  
Amount of oil between min. and max. marks = approx. 0.3 liter (0.6 pint).  
Never wipe off dipstick with a cloth losing limit.



An oil dipstick with a longer measuring tip (1) is standard since 2.85.  
This makes it possible to report the oil level in the transmission earlier.  
The oil level should not be below ball (2) after a test drive and an oil temperature of 40° C (104° F).  
The oil level should be between the min. and max. marks with an oil temperature of approx. 80° C (175° F).

Note:  
The new oil dipstick can be installed retroactively.

#### Important!

#### Oil Level Too High:

Strong foaming, oil splash loss, high temperature when driving fast, oil lost through vent.

#### Oil Level Too Low:

Valves rattling, foaming, engine slipping in curves, general operating disturbances.

Always only pour in ATF through funnel 24 0 080.



## 24-108



**BMW 325iX:**  
 Unscrew propeller shaft at front end – see 26 20 000.  
 Unscrew reinforcement plate on engine and transmission and loosen 2 screws of oil level switch enough until the reinforcement plate can be removed after bending holder (1).

**Important!**  
 Use spacer (2) between the bolt and case to prevent scraping of the Torr case on the front propeller shaft section.

Unscrew torque converter on drive plate at three points.  
 Turn flywheel for this step.

**Important! – Installation:**  
 Tightening torque\*  
 Only use size M 10 x 16 mm bolts together with spring washers.  
 Non-conformance will lead to destruction of the transmission.


**Only Version with DME:**  
 Unscrew bolts.  
 Pull out speed sensor (1) and reference mark sensor (2).

**Important! – Installation:**  
 Check installed position.  
 Plugs must not be mixed up. Install speed sensor (1) in bore (D) and reference mark sensor (2) with ring (3) in bore (B).  
 Engine can not be started if plugs are mixed up.

**Installation:**  
 Check O-rings.  
 Install sensors with Molykote Long-term 2.  
**Important!**  
 Keep grease and dirt off of face of DME sensors.

730 24 056

\* See Specifications



**Only for Cars with EH Transmission:**  
 Turn bayonet fastener (1) to the left.  
 Pull off plug (2).  
 Lift wire harness out of holders.



**Installation:**  
 Connect plug (2) in such a manner that marking lines are aligned.

Support transmission with Special Tools 24 0 120 and 00 2 020.  
 Remove cross member.

**Installation:**  
 Center transmission – see Group 26.  
 Tightening torque\*.

Unscrew joint disc on transmission.  
 Disconnect shift rod (1).

**Installation:**  
 Adjust shift – see 24 00 006.



**Installation:**  
 Replace stop nuts.  
 Tighten nuts with a standard 17 mm socket and torque wrench.  
 Tightening torque\*.

**Important!**  
 Only tighten nuts (never bolts) to avoid stress in the joint disc.

\* See Specifications




## 24-110

### 24 00 042 INSTALLING EXCHANGE TRANSMISSION

Remove transmission — see 24 00 022.

**Important!**

Always clean oil cooler and lines with compressed air and flush twice with ATF prior to installation of an exchange transmission. Transmission identification\* is on data plate. Version with Shift Linkage: Transfer transport holder (1) and linkage (2) with lever.



733 24 240

Mount spring clamp from top to bottom.

**Important!**  
Bearing sleeve.




30 24 018

Version with Shift Cable:  
Transfer transport holder (1), lever (2) and bracket (3).



20 24 020

Transfer rubber mounts and exhaust holders.



733 24 281

Transfer screwed adapters (3).  
Version with Multiple Internal Teeth:  
Unscrew threaded adapters with a 12 mm multiple tooth socket or T 55 Torx socket. Replace seals.  
Tightening torque\*.

**Important! — Installation:**  
Automatic transmissions are supplied filled with oil since 1.86.

Remove plug in oil sump prior to installation of the oil filler pipe.  
Catch escaping ATF in a clean container.  
Pour ATF into transmission through a Tunnel (Special Tool 24 0 080) after installation of transmission.



30 24 006

**Check oil level.**

The oil dipstick installed standard since 2.85 has a longer measuring tip.  
This means displaying the oil level in the transmission earlier.  
The oil level should not be below ball (2) after a test drive and with an oil temperature of approx. 40° C (105° F).  
The oil level should be between the min. and max. marks with an oil temperature of about 80° C (175° F).  
Correct oil level, if necessary.

**Note:**


The new oil dipstick can be installed retroactively.  
Oil Level Too High:  
Excessive foaming, splash loss, high temperature when driving fast and oil lost via the vent.  
Oil Level Too Low:  
Valves rattling, foaming and engine slipping. Also general disturbances.



733 24 280


## 24-112

Loosen bolt (1) with Special Tool 00 2 100 enough, that bracket (2) can be folded down. Remove parking lock pawl, spring and shaft.  
**Caution!**  
Spring force.




Pull off parking lock gear and governor.

**Note:**  
Check for spacer between output flange and parking lock gear.  
The parking lock gear of version with spacer (5) has to be pulled off with Special Tool 23 1 050.




Version with Transfer Box:  
Lift out snap ring (1) and slide forward.


**Installation:**  
Replace snap ring.



Pull bearing sleeve (2) off of input shaft with Special Tool 00 8 500.



**Installation:**  
Install snap ring (1) in groove of output shaft. Heat bearing sleeve (2) to about 80° C (175° F) with a hot air blower and slide on to output shaft against stop ring (1).



Lift off circlip (3).  
Pull off parking lock gear and governor.




## 24-114

Remove snap ring (8) with help of two screw-

drivers.  
*Installation:*  
 Replace snap ring (8).




Pull out clutch B with two locally made hooks.  
*Installation:*  
 Lift clutch until resistance is noticed and push back again.  
 Pull out clutch with one firm pull.  
 This will also pull out support (9) and seal (10).




Sketch to make up hooks locally.  
 Dimensions in mm.




Lift out snap ring (11).




Apply Special Tool 24 0 040 on intermediate shaft.




Pull out entire set.



Remove angled washer (12), axial bearing (13) and thrust washer (14).




Remove 4th gear clutch set.




## 24-116

Hold angled washer (1) on cylinder A with grease (vaseline).




Insert and move clutch A back and forth, until teeth of plate carrier and plates mesh.


*Note:* Clutch A is in correct installed position, if distance (B) from cylinder A to the case sealing surface is approx. 8 mm (0.315").




Install angled washer (3) with its collar facing up and axial bearing (2).



Hold gasket and thrust washer (1) in position with grease (vaseline).



Mount converter bell housing and tighten all bolts. Tightening torque\*.





Check axial play of input shaft. Mount Special Tool 24 0 010 to locate the input shaft.

Install Special Tool 00 2 510 (dial gage). Measure axial play by pulling the input shaft. Specifications: 0.2 to 0.4 mm (0.008 to 0.016"). If play deviates, remove converter bell housing again and replace the thrust washer with a thicker or thinner one.


Recheck axial play. Bolt down converter bell housing. Tightening torque\*.

Remove Special Tool 24 1 010.




Lubricate O-ring (3) with ATF. Slide on parking lock gear and governor.

*Note:* Use shim between governor and output flange — for version without spacer.




\* See Specifications

## 24-118





Screw in valve body mounting bolts.  
*Important!*  
Bolts differ in length.  
Bolts (1) = 65 mm (2.559").  
Bolts (2) = 60 mm (2.362").

Tighten valve body bolts only finger tight.  
Align valve body with Special Tool 24 3 050.  
Distance between valve body case and throttle pressure piston must be 11.5 mm (0.453").




Tighten valve body bolts.  
Tightening torque\*.  
Tighten bolts with Special Tools 00 2 100 and 00 2 050.




EH Transmission:  
Check O-ring (4), replacing if necessary.  
Install socket with the flat side facing out and bolt.  
Tightening torque\*.

\* See Specifications




*Note:*  
Also mount pulse transmitter on valve body.  
Engage tabs of holder (5) in grooves of plug.

Install O-ring (1) between valve body and oil filter screen.  
Install and bolt down oil filter screen.  
Tightening torque\*.  
Check length of bolts.  
Length = 65 mm (2.559").




Place magnets (1 and 2) in oil sump.  
Install gasket (3).



Install oil sump and tighten bolts with brackets.  
Tightening torque\*.  
*Important!*  
Both brackets with straight, short legs must be mounted on straight side of the oil sump.

\* See Specifications




## 24-120

### 24 11 052 REMOVING AND INSTALLING OR SEALING TRANSMISSION SION EXTENSION

Unscrew propeller shaft - 24 00 022.  
Lift out lockplate (1).

*Installation:*  
Replace lockplate.



Apply Special Tool 23 1 200.  
Hold output flange with Special Tool  
23 0 020.  
Unscrew collar nut with Special Tool  
23 1 210.

*Installation:*  
Tightening torque\*.

Pull off output flange.





Support transmission with Special  
Tools 24 0 120 and 00 2 020.  
Remove cross member with rubber  
mounts.  
Lower transmission.

*Installation:*  
Center transmission - see Group 26.  
Tightening torque\*.

Unscrew transmission extension.

*Installation:*  
Replace gasket (1).  
Tightening torque\*.




\* See Specifications

## 24-122

24 12 103 REPLACING RADIAL OIL SEAL  
FOR MANUAL SHIFT VALVE  
SHAFT

Detach selector lever (1) at transmission.



Remove radial oil seal (2).

*Installation:*  
Lubricate sealing lip with ATF.  
Knock in radial oil seal.

# 24-124

## 24 23 022 REPLACING MULTIPLE PLATE CLUTCHES AND BRAKES

Disassemble transmission 24 00 082.

*Important!*

Check whether the transfer plate has a venting valve when repairing clutch A (see 24 16 502). If applicable, install a transfer plate with a venting valve.


Clutch A:

Press out input shaft (1).  
Check O-ring (2), replacing if necessary.



733 24 171

Compress clutch set and remove snap ring (3).  
Remove plate carrier (4).



733 24 172

Lift out plate set and diaphragm spring.


*Note:*

Note quantity of steel and lined plates.




733 24 173

Press out clutch A piston with compressed air applied through oil bore.




733 24 174



733 24 175

*Installation:*  
Replace O-rings (5 and 6).  
Lubricate O-rings with light coat of ATF to make installation easier.



733 24 176

*Installed Order of Plates:*  
Note number of removed steel and lined plates, and install same plates beginning with a spring and steel plate.  
1 Spring plate.  
2 Steel plates (1.8 mm)  
3 Lined plates  
4 Plate carrier.

Place diaphragm spring in input shaft case with curved surface facing down.  
Insert plate set with plate carrier.  
Compress clutch set and insert snap ring.




733 24 177




# 24-128


Disassemble planet gear set.  
Remove support ring (1).  
*Installation:*  
Mount support ring with fins facing down.



Take off planet gear set (2).




Pull out sun gear shaft (3).




Remove axial bearing (4) and thrust washer (5).




Lift out snap ring (6).




Remove hollow gear (7) and planet plate (8).



Remove thrust washers (9) and axial bearing (10).  
Take off spacer (11).




Lift out snap ring (12).  
Take off hollow gear (13).



733 24 202


# 24-132

Use plate carrier (3) to turn one-way clutch  
outer race clockwise and mount race on inner  
race.



733 24 231

Clearance between one-way clutch inner race  
and outer race should be at least 0.1 mm  
(0.004").



733 24 232




## 24-134

### 24 31 002 REMOVING AND INSTALLING PRIMARY PUMP

Remove torque converter 24 40 003.  
Take off converter ball housing with connecting

plate.

*Installation:*  
Tightening torque\*.



*Installation:*  
Mount angled washer (1) with collar facing

needle bearing (2) on input shaft.  
Hold thrust washer (3) on converter ball hous-

ing with grease.  
Replace gasket (4).

Unscrew primary pump on converter ball hous-

ing.  
Loosen two bolts opposite each other by only



several turns.  
Loosen primary pump on converter ball hous-

ing with several light knocks.

Remove primary pump.

*Installation:*  
Centering pin (5) must engage in bore (6).

\* See Specifications



*Installation:*  
Primary pump, consisting of pump body (7),  
hollow gear (8) and impeller (9), may only be  
replaced as an assembly.

Check O-ring (10), replacing if necessary.  
*Important!*  
Install hollow gear (8) and impeller (9) that  
punch marks face up.

Check radial play\* between driven gear and  
pump body, while turning gear 360°.

Check axial play\* of both gears to face surface  
with a precision depth micrometer.


Check running of primary pump with Special  
Tool 24 3 140.

\* See Specifications



30 24 027

*Installation:*  
 Install snap ring (1) in groove of output shaft.  
 Install heat bearing sleeve (2) to approx. 80° C  
 (175° F) with a hot air blower and push on  
 to output shaft against the snap ring.



30 24 028

Lift out circlip (3).  
 Pull off parking lock gear.  
 EH Transmission:  
 Remove parking lock pawl — see 24 34 002.




24 32 505 DISASSEMBLING AND  
 ASSEMBLING CENTRIFUGAL  
 GOVERNOR  
 — Centrifugal Governor Removed —

Unscrew parking lock gear on centrifugal  
 governor.  
*Installation:*  
 Tightening torque\*.

20 24 031


Unscrew cover (1) on housing (2).  
 Lift out retainer (3) and take off washer (4).  
 Remove governor plunger (5), spring (6) and  
 governor sleeve (7).

*Installation:*  
 Governor plunger must slide easily in the  
 governor sleeve.  
 Remove spring retainer (8) and balance  
 weight (9).



## 24-138

Connect throttle cable in suspension on transmission and holder (1).  
Tighten cable.  
Squeeze loose lead seal on cable at distance (A) = 0.25 to 0.50 mm (0.010 to 0.020").  
Adjust throttle cable 24 00 006.






*Installation:*  
Install selector shaft.  
Preload spring (3) by one turn anticlockwise with throttle cam (4).  
Connect nipple on throttle cam.


### 24 34 702 REPLACING SPRING FOR THROTTLE CABLE

Remove valve body 24 30 002.  
Disconnect selector lever (1) on transmission.  
Disconnect throttle cable.

Drive out pin (2) in position N.


Pull out selector shaft far enough that spring (3) can be removed.





**24 34 860 REPLACING PRESSURE REGULATOR**  
 — Valve Body Removed —

- Pull off wire plug.
- Unscrew Torx bolt with Special Tool 00 2 100.
- Take off holder.
- Pull out pressure regulator (5).
- Important! — Installation:*
- Arrow (7) on pressure regulator must be aligned with rib (8).
- Install holder with tabs facing collar on pressure regulator.
- Tightening torque\*.



**24 34 870 REPLACING PULSE TRANSMITTER**  
 — Oil Sump Removed —

- Unscrew Torx bolts (1 and 3) with Special Tool 00 2 100.
- Take off holder (2).
- Installation:*
- Engage tabs on holder (2) in grooves of plug (4).
- Pull out pulse transmitter.
- Pull off plug (5).
- Installation:*
- Tightening torque\*.

733 24 258

\* See Specifications

# 24-145

## TROUBLESHOOTING AUTOMATIC TRANSMISSION 4 HP 22 / H

Condition	Cause	Correction
Position P	Selector linkage or cable between selector lever and transmission maladjusted	Adjust selector lever 24 00 006
Park will not engage	Excessive friction in parking lock mechanism	Replace parking lock parts (connecting rod, pawl) 24 34 002
Park does not hold (slips out)	Selector linkage or cable between selector lever and transmission maladjusted	Adjust selector lever 24 00 006
Engine cannot be started in N or P	Transmission switch defective	Replace transmission switch 25 16 080
Position R	Selector linkage or cable between selector lever and transmission maladjusted	Adjust selector lever 24 00 006
No reverse gear	Oil filter screen dirty	Replace oil filter screen Replace transmission if inner bits are found in oil sump
	Clutch B destroyed — in this case also no 3rd gear	Disassemble clutches 24 23 022
	Brake D destroyed — in this case also no engine braking in 1st gear of position 1	Disassemble clutches 24 23 022
	Clutch E destroyed — in this case also no engine braking in 2nd and 3rd gears as well as 1st gear in position 1	Disassemble clutches 24 23 022
	Reverse gear arrest does not cancel	Replace valve body 24 30 002
	Clutch B or E or brake D damaged	Disassemble clutches 24 23 022
Slipping or shaking when moving off	Damper B defective — in this case shift 2-3 also not correct	Replace valve body 24 30 002
Hard engaging jolt P-R or N-R or definite double knock for P-R or N-R shifts (engine speed < 1500 rpm)		

## 24-147

Condition	Cause	Correction
Car drives in 2nd gear	Governor bushing seized Shift valve 1-2 seized	Clean or replace governor 24 32 002 Replace valve body 24 30 002
Car drives in 3rd gear	Governor bushing seized Shift valves 1-2 and 2-3 seized	Clean or replace governor 24 32 002 Replace valve body 24 30 002
Car shifts 1-3	Shift valve 2-3 seized	Replace valve body 24 30 002
Shift Points*		
Zero load shift not correct	Governor dirty Shift valve sticks	Clean or replace governor 24 32 002 Replace valve body 24 30 002
Full load shift points not correct	Throttle cable maladjusted	Adjust throttle cable 24 00 006
No kickdown shift	Throttle cable maladjusted Throttle cable maladjusted 4-3 kickdown valve seized	Adjust throttle cable 24 00 006 Adjust throttle cable 24 00 006 Replace valve body 24 30 002
Shift Transitions		
Zero load shifts too hard	Damper defective Modulation pressure too high Plates damaged	Replace valve body 24 30 002 Replace valve body 24 30 002 Disassemble transmission 24 00 082
Full load and kickdown shifts too long	Damper defective Modulation pressure too low Plates damaged	Replace valve body 24 30 002 Replace valve body 24 30 002 Disassemble transmission 24 00 082
Full load and kickdown shifts too hard	Modulation pressure deviates Damper defective	Replace valve body 24 30 002 Replace valve body 24 30 002

\* See Specifications



## 24-149

Condition	Cause	Correction
Throttle cable sticks	Nipple disconnected on throttle cam Excessive friction in throttle cable sleeve	Replace throttle cable 24 34 102 Replace throttle cable 24 34 102
Throttle pressure piston seized	Throttle pressure piston clamped Oil filter screen on valve body dirty	Replace valve body 24 30 002 Replace oil filter screen and, if burnt clutch liner bits are found in oil sump, also replace transmission
Noises and power flow interruption after long drive	Drive plate between converter and engine torn off	Replace drive plate or converter 11 22 051 or 24 40 003
No forward or reverse drive, loud noise		
<b>Noises</b>		
Loud noise in all positions, especially with cold oil. Oil pump intake noise.	Oil level too low Valve body leaks Oil filter screen dirty	Correct oil level Replace valve body 24 30 002 Replace oil filter screen and, if burnt clutch liner bits are found in oil sump, also replace transmission
Loud, screeching noise depending on speed in all positions, especially with warm oil; occurring after long drive, some-times accompanied by breaks in power flow	Torsion damper defective	Replace converter 24 40 003
Loud noise when converter closes	Engine speed too low, converter shift point not correct	Replace valve body 24 30 002
Loud engine grumble when converter closes		
<b>Leaks</b>		
Oil dripping out of converter bell housing	Seal in pump body damaged Pump body leaks Converter leaks on welded seam Radial oil seal for converter leaks	Replace seal 24 31 002 Replace pump assy. 24 31 002 Replace converter 24 40 003 Replace radial oil seal 24 12 003
Leak between transmission case and oil sump	Oil sump mounting bolts not tightened correctly Oil sump gasket damaged	Tighten bolts to specified torque* Replace gasket 24 11 002
Leak between transfer plate and transmission case (especially in area of pump pressure bore)	Mounting bolts on converter bell housing loose	Tighten bolts to specified torque*
Oil lost through throttle cable connection	O-ring on connection damaged	Replace O-ring or, if necessary, entire throttle cable 24 34 102

\* See Specifications

## 24-153

Condition	Cause	Correction
Position D	Oil filter screen dirty	Replace oil filter screen 24 31 152 Exchange transmission, if liner bits are found in oil sump
No power flow	Clutch A faulty	Replace clutch A 24 23 022
	1st gear one-way clutch slips	Disassemble transmission 24 00 082
	Linkage between selector lever and transmission maladjusted	Adjust selector linkage 24 00 006
	Clutch A damaged	Replace clutch A 24 23 022
	Clutch A damaged	Replace clutch A 24 23 022
	Damper A faulty	Replace valve body 24 30 002
	Slipping or shaking while moving off	Replace kickdown switch
	Hard engaging jolt N-D (engine speed 1500 rpm)	Check transmission electronics (see test plan)
	No shift (warm or cold state)	Replace solenoid 24 34 851
	- Shift 1-2 / 2-1	Replace valve body 24 30 002
	Kickdown switch faulty (only kickdown shifts)	Replace valve body 24 30 002
	Transmission electronics faulty	Replace valve body 24 30 002
	Solenoid (1) faulty (see test plan)	Replace valve body 24 30 002
	Control valve 1-2 / 3-4 seized	Replace valve body 24 30 002
	Shift valve 1-2 seized	Disassemble clutches 24 23 022
	Brake C' and/or C faulty	Replace solenoid 24 34 851
	- Shift 1-2	Replace valve body 24 30 002
	Solenoid (2) faulty (see test plan)	Replace valve body 24 30 002
	- Shift 2-3 / 3-2	Replace clutch B 24 23 022
	Shift valve 2-3 seized	Replace clutch B 24 23 022
	Clutch B faulty	Replace solenoid 24 34 851
	- Shift 2-3	Replace valve body 24 30 002
	Solenoid (1) defective (see test plan)	Replace valve body 24 30 002
	Control valve 1-2 / 3-4 seized	Replace valve body 24 30 002
	Shift valve 3-4 seized	Disassemble clutches 24 23 022
	Brake F faulty	Replace program switch
	- Shift 3-4	Replace pulse transmitter 24 34 870
	Program switch faulty (see test plan)	
	Pulse transmitter faulty (see test plan)	
	- Shift 1-2	
	Engine speed does not go beyond stall speed in drive and full load	

## 24-155

Condition	Cause	Correction
Full load and kickdown shifts too hard	Modulation pressure not okay Damper faulty Control unit faulty	Replace valve body 24 30 002 Replace valve body 24 30 002 Replace control unit 24 61 000
Position 3 — 3rd Gear	Clutch E damaged	Disassemble clutches 24 23 022
No engine braking effect	Clutch E damaged	Disassemble clutches 24 23 022
Position 2	Transmission electronics faulty	Check transmission electronics (see test plan)
Manual downshift 3-2 not okay	Solenoid (2) faulty (see test plan)	Replace solenoid valve 24 34 851
No engine braking effect	Brake C' or clutch E damaged	Disassemble clutches 24 23 022
Position 1	Transmission electronics faulty	Check transmission electronics (see test plan)
Manual downshift 2-1 not okay	Solenoid (1) faulty (see test plan)	Replace solenoid valve 24 34 851
No engine braking effect	Brake D or clutch E damaged	Disassemble clutches 24 23 022
Converter Clutch	Control unit faulty	Replace control unit 24 61 000
Shift speed not okay	Converter clutch damper defective	Replace valve body 24 30 002
Shift transition too hard	Converter not okay	Replace converter 24 40 003
No shift	Transmission electronics defective Solenoid (3) faulty (see test plan) Converter faulty	Check transmission electronics (see test plan) Replace solenoid valve 24 34 851 Replace converter 24 40 003
Converter clutch always locked (engine stops in drive position)	Transmission electronics faulty Solenoid (3) faulty (see test plan)	Check transmission electronics (see test plan) Replace solenoid valve 24 34 851

## 24-157


Condition	Cause	Correction
<p><u>Leakage</u> Oil dripping out of converter bell housing</p>	<p>Seal in pump body damaged Pump body leaks Converter leaks on welded seam Radial oil seal for converter leaks</p>	<p>Replace seal 24 31 002 Replace complete pump 24 31 002 Replace converter 24 40 003 Replace radial oil seal 24 12 003</p>
<p>Leak between transmission case and oil sump</p>	<p>Oil sump mounting bolts not tightened with correct torque Oil sump gasket damaged Converter bell housing mounting bolts loose</p>	<p>Tighten bolts with correct torque* Replace gasket 24 11 002 Tighten bolts to correct torque*</p>
<p>Leak between transfer plate and transmission case (especially in area of pump pressure bore)</p>	<p>Converter bell housing mounting bolts loose</p>	<p>Tighten bolts to correct torque*</p>
<p>Oil loss on transmission plug</p>	<p>O-ring faulty</p>	<p>Replace O-ring 24 30 002</p>
<p>Oil loss on output</p>	<p>Radial oil seal on output damaged</p>	<p>Replace radial oil seal 24 12 013</p>
<p>Oil loss through or on vent</p>	<p>Oil level too high Wrong type of oil (strong foaming) Vent cover missing O-ring on vent damaged</p>	<p>Correct oil level Replace oil, if necessary remove transmission and drain entire oil including that in converter Mount cover or replace vent Unscrew transmission extension, replace O-ring</p>
<p>Oil loss on cooler line</p>	<p>Circlip pre-load insufficient Loose connection Cooler line damaged Cooler leaks</p>	<p>Replace circlip Tighten bolts to correct torque* Replace cooler line Replace cooler 17 11 000</p>
<p>Oil loss on transfer plate</p>	<p>Plug on transfer plate leaks</p>	<p>Tighten plug with correct torque* Replace seal</p>
<p>Leak between transmission case and transmission extension</p>	<p>Mounting bolts loose Gasket damaged</p>	<p>Tighten bolts with correct torque* Replace gasket 24 11 052</p>

\* See Specifications

## 24-159

Condition	Cause	Correction
Position D	Solenoid (2) faulty (see test plan) Wire to solenoid (2) grounded out (see test plan)	Replace solenoid valve 24 34 851 Replace wire harness
No shift function 2-3 / 3-2	Shift valve 2-3 seized	Replace valve body 24 30 002
No shift function 3-4 / 4-3	Solenoid (1) faulty (see test plan) Control valve 1-2 / 3-4 seized	Replace solenoid valve 24 34 851 Replace valve body 24 30 002
Shifts 1-2 / 2-3 / 3-4 too long	Pressure regulator faulty (see test plan) Wire to pressure regulator grounded out (see test plan) Damper faulty	Replace pressure regulator 24 34 860 Replace wire harness Replace valve body 24 30 002
Upshifts 1-2 / 2-3 / 3-4 too hard	Modulation valve, pressure reducing valves 1 and 2 seized	Replace valve body 24 30 002
	Pressure regulator faulty (see test plan)	Replace pressure regulator 24 34 860
	Modulation valve sticks	Replace valve body 24 30 002
	Damper faulty	Replace valve body 24 30 002
Downshift 4-3 too hard	Plate F dirty	Replace valve body 24 30 002
Manual downshifts 4-3 / 3-2 too hard	Damper E or C' faulty	Replace valve body 24 30 002

# 24-161



735 24 017

## AEGS LAYOUT DRAWING

- 1 AEGS control unit
- 2 Kickdown switch
- 3 Program switch
- 4 Position switch
- 5 Transmission
- 6 Fault indicator
- 7 Ignition
- 8 Fuel injection
- 9 DME control unit
- 10 Air flow sensor
- 11 Engine speed sensor
- 12 Throttle valve sensor
- 13 Temperature sensor
- Y1 Solenoid — 1st/2nd and 3rd/4th gears
- Y2 Solenoid — 2nd/3rd gears
- Y3 Solenoid — converter lockup clutch
- Y4 Solenoid — reverse gear lock
- Y5 Pressure regulator
- Y6 Pulse transmitter
- tD Speed signal
- tI Load signal
- VL Full load
- ME Engine tap
- PS Position switch

## 24-165

Explanations for Independent Electronic Transmission Control (AEGS):  
 There is a comprehensive test of the entire AEGS each time the engine is started.  
 Turn on ignition.  
 The yellow fault indicator lamp in the instrument panel will flash twice briefly, stay on while starting and go out at an engine speed above 450 rpm.

Test Position: Fault Indicator	Cause	Correction
Fault indicator does NOT flash and remains on after starting.	Break in ground wire 5/19. Check voltage between wires 5/19 and 24 with ignition on. Nominal value: 5 V. AEGS control unit faulty.	Repair to wiring diagram. Repair wire to wiring diagram. Replace control unit 24 61 000.
Fault indicator flashes, but remains on after starting.	Power supply to AEGS control unit insufficient. Check voltage between wires 5/19 and 35 with ignition on. Nominal value: > 10 volts. Wires to solenoid 1 (Y1), 2 (Y2), reverse gear (Y4) or converter lockup clutch (Y3) have a break or are grounded out. See test plan for checking. No TD signal from DME control unit. No ti signal from DME control unit.	Repair wire to wiring diagram. Repair wires to wiring diagram. Check plug connection (X) and power supply lead to AEGS control unit.
Fault indicator comes on while driving.	Power supply between wires 5/19 and 35 insufficient (drops below 10 V). TD signals stop suddenly. Break in positive wires to solenoids.	Repair wires to wiring diagram. Repair wires to wiring diagram.

Troubleshooting — also refer to Service Information 24 02 85 (422).

# 24-167

Solenoid valve (Y4) — reverse gear lock. ————— no —————> Wire to solenoid valve damaged /grounded out. —————> Repair wire.  
Insulation test (M 06). —————> Check plug connections. —————> Repair plug connections.  
Measure resistance between wires 5/19 and 1/20. —————> Solenoid valve grounded out. —————> Replace solenoid valve 24 34 851.  
Nominal value: > 500 k-ohms.

d) Solenoid valve (Y3) — converter lockup clutch. ————— no —————> Wire to solenoid valve damaged/shorted. —————> Repair wire.  
Resistance test (M 06). —————> Check plug connections. —————> Repair plug connections.  
Measure resistance between wires 1 and 25. —————> Solenoid valve faulty. —————> Replace solenoid valve 24 34 851.  
Nominal value: approx. 22 ... 60 ohms.

Insulation test (M 06). ————— no —————> Wire to solenoid valve damaged/grounded out. —————> Repair wire.  
Measure resistance between wires 5/19 and 1/25. —————> Solenoid valve grounded out. —————> Replace solenoid valve 24 34 851.  
Nominal value: > 500 k-ohms.

## Test Position 3

Pressure regulator (Y5). ————— no —————> Wire to pressure regulator damaged/shorted. —————> Repair wire.  
Resistance test (M 06). —————> Check plug connections. —————> Repair plug connections.  
Measure resistance between wires 1 and 22. —————> Pressure regulator faulty. —————> Replace pressure regulator 24 34 860.  
Nominal value: 1.7 ... 4.5 ohms.

Insulation test (M 06). ————— no —————> Wire to pressure regulator damaged/grounded. —————> Repair wire.  
Measure resistance between wires 5/19 and 1/22. —————> Solenoid valve grounded out. —————> Replace solenoid valve 24 34 851.  
Nominal value: > 500 k-ohms.



Test Position 7

Pulse transmitter (Y6).  
Resistance test (M 06).  
Measure resistance between wires 8 and 27.  
Nominal value: 0.7 ohms ... 1.8 k-ohms.

no → Wire to pulse transmitter damaged/shorted. → Repair wire.  
Check plug connections.  
Pulse transmitter faulty. → Repair plug connections.  
Replace pulse transmitter 24 34 870.

Insulation test (M 06).  
Measure resistance between wires 5/19 and 8/27.  
Nominal value: > 500 k-ohms.

no → Wire to pulse transmitter damaged/grounded out. → Repair wire.  
Pulse transmitter grounded out. → Replace pulse transmitter 24 34 870.

Dynamic test (M 22).  
Scope test.  
Connect test lead between wires 8 and 27 (see operating instructions for BMW Service Tester).  
Support car underneath the trailing arms. It should be possible to turn the rear wheels easily.  
Start engine.  
Selector position D.  
Speed approx. 30 km/h (25 mph).  
All sine curves must be uniformly larger than 0 ... 10 (left screen scale).



no → Pulse transmitter faulty. → Replace pulse transmitter 24 34 870.  
Wire to pulse transmitter damaged/grounded out. → Repair wire.

# 25 Gear Shift Mechanism

<b>SHIFT LAYOUT DRAWING — MANUAL TRANSMISSION</b>	
— Sheet metal shift console .....	25 - 1
— Aluminum shift console .....	25 - 2
<b>25 11 000</b> Shift lever — remove and install	
— Sheet metal shift console .....	25 - 3
— Aluminum shift console .....	25 - 4
— All wheel drive cars .....	25 - 5
<b>003</b> Shift lever — disassemble and assemble	
— Sheet metal shift console .....	25 - 7
— Aluminum shift console .....	25 - 8
<b>081</b> Shift lever dust cover — replace	
— Sheet metal shift console .....	25 - 8
<b>111</b> Shift rod joint — replace	
— Sheet metal shift console .....	25 - 9
— Aluminum shift console .....	25 - 10
— All wheel drive cars .....	25 - 11
<b>211</b> Shift lever console — replace	
— Sheet metal shift console .....	25 - 12
— Aluminum shift console .....	25 - 13
<b>SHIFT LAYOUT DRAWING — AUTOMATIC TRANSMISSION</b>	
— Version with shift rod .....	25 - 15
— Version with cable .....	25 - 16
<b>25 16 050</b> Selector lever complete with base — remove and install	
— Version with shift rod .....	25 - 17
— Version with cable (all wheel drive) .....	25 - 18
<b>080</b> Selector lever — remove and install	
— Version with shift rod .....	25 - 19
— Version with cable (all wheel drive) .....	25 - 20
<b>202</b> Cable for range selector lever — replace	
— Cable for range selector lever — adjust .....	25 - 21
...	25 - 22

# 25-1

## SHIFT LAYOUT FOR MANUAL TRANSMISSION - Sheet Metal Shift Console -




- 1 Selector arm
- 2 Console
- 3 Bolt
- 4 Bolt
- 5 Nut
- 6 Selector rod
- 7 Spacer
- 8 Circlip
- 9 Selector rod joint
- 10 Pin
- 11 Lubricating felt
- 12 Spring sleeve
- 13 Lower plate
- 14 Damper plate
- 15 Rubber cover
- 16 Rubber mount
- 17 Holder
- 18 Cap
- 19 Circlip
- 20 Shift lever upper section
- 21 Shift lever assembly
- 22 Circlip
- 23 Shift lever lower section
- 24 Upper plate
- 25 Spring
- 26 Spacer
- 27 Circlip
- 28 Rubber ring
- 29 Washer
- 30 Dust cover
- 31 Shift lever knob

## 25-3


### 25 11 000 REMOVING AND INSTALLING SHIFT LEVER — Sheet Metal Shift Console —

1. Remove retainer (1).
2. Take off washer (2).
3. Pull out selector rod (3).

Remove dust cover.



- Lift out circlip (4).  
Remove shift lever.  
*Installation:*  
Lubricate spherical plates with Molykote  
Longterm 2.




30 25 022




30 25 010

Remove insulating felt.  
Pull out cover between body and shift  
console.



30 25 011

*Installation:*  
Check for correct fit of cover.




30 25 23

## 25-5

### 25 11 000 REMOVING AND INSTALLING SHIFT LEVER — All Wheel Drive —

Remove exhaust assembly 18 00 020.  
Unscrew heat shields.



30 27 010

Loosen threaded sleeve several turns with  
Special Tool 26 1 060 or 26 1 040.


*Installation:*  
Tighten threaded sleeve with Special Tool  
26 1 060 or 26 1 040 after finishing installa-  
tion.  
Tightening torque\*.



26 1 040

30 27 011

Support transmission.  
Unscrew cross member.  
Lower transmission to front axle carrier.  
*Installation:*  
Check length of bolts.



30 27 018


Pull off shift lever knob.



28 25 003

\* See Specifications


Lift out dust cover.



28 25 004


Remove felt.  
Disconnect plug on wires for backup lights.  
Unclip dust cover (1) on body and pull off of  
shift lever.  
Disconnect dust cover (2) on shift console.

*Installation:*  
Inspect dust covers.  
Check for correct seating.




630 25 043

Lift out circlip (1).  
Take off washer (2).  
Pull out selector rod (3).



30 25 030

Apply Special Tool 25 1 100.  
Turn counterclockwise 90°.  
Push up spherical plate.  
Remove shift lever from above.



25 1 100

30 25 031

# 25-7

## 25 11 003 DISASSEMBLING/ASSEMBLING SHIFT LEVER — Sheet Metal Shift Console —


Remove shift lever 25 11 000.  
Lift out wire snap ring.




Pull off shift lever upper section.  
*Installation:*  
Check installed position.



Pull off cap (1).  
Remove circlip (2).  
Remove rubber ring (3), washer (4), snap ring (5) and rubber part (6).



Remove circlip (7), spring retainer (8), spring (9), upper plate (10) and lower (ribbed) plate (11).  
*Installation:*  
Lubricate upper and lower plates with Molykote Longterm 2.



25 11 111 REPLACING SELECTOR ROD JOINT  
 — Sheet Metal Shift Console —

Access to the selector rod joint differs in accordance with the different transmission and propeller shaft versions.  
 Remove exhaust assembly 18 00 020.  
 Remove heat shield with reinforcement carrier.




3026 001

Version with 4 Speed Transmission:  
 Unscrew console mounting bolts.

**Important!**  
 Self-locking bolts — will be difficult to unscrew.  
**Installation:**  
 Use new bolts coated with micro-encapsulating adhesive.  
 Tightening torque\*.


Version with 5 Speed Transmission:  
 Unscrew propeller shaft on transmission, see 26 11 000.



3025 014


2025 001

Version with 5 Speed Transmission and Vibration Damper:  
 Unscrew propeller shaft on transmission, see 26 11 000.  
 Unscrew output flange with vibration damper on transmission, see 23 12 053.




30 23 123

\* See Specifications



3025 022


Engage reverse gear.  
 Lift out circlip (1).  
 Take off washer (2).  
 Pull out selector rod (3).



20 25 008

Move selector shaft to 3rd or 5th gear position.  
 Drive out pin.  
 Remove selector rod with joint.

**Note:**  
 If selector rod joint has an offset bearing sleeve, install the bearing sleeve offset to the right as seen locking forward in car.  
 Cars with Vibration Damper:  
 Install bent selector rod offset to the left.



20 25 009

**Installation:**  
 Lubricate bearing sleeve and joint with Molykote Longterm 2.




20 25 010

## 25-11

### 25 11 111 REPLACING SHIFT ROD JOINT

— All Wheel Drive —

- Remove and install transfer box — see 27 10 010.
- Lift out retainer (1).
- Take off washer (2).
- Pull out shift rod (3).



30 25 030


Push back locking sleeve.



30 25 034

Drive out pin.  
Remove shift rod with joint.

*Note:*  
Bearing sleeve is offset to the right as seen looking forward in car.



30 25 035

*Installation:*  
Check damper in joint, replacing if necessary.



30 25 047

Lift out retainer (1).  
Take off washer (2).  
Pull out shift rod.

*Installation:*  
Check rubber rings (3), replacing if necessary.  
Lubricate bearing surfaces with Molykote Longterm 2.





## 25-17

### 25 16 050 REMOVING AND INSTALLING

SELECTOR LEVER COM-  
PLETE WITH BASE  
— Version with Shift Rod —

Remove center console — see 51 16 200.

Lift out retainer.


Disengage shift rod.

*Installation:*

Adjust shift rod — see 24 00 004.



20 25 015



30 25 017


Disconnect plug (2).

Remove bolts (3).

Remove base.

*Installation:*

Be careful not to pinch the wire harness.



20 25 022

*Installation:*

Insert insulator (4).

## 25 - 19

Unscrew screw on handle.  
Pull off handle.



30 25 019

*Installation:*  
Guide pin of push button into pull rod hole.



20 25 028

Take pull rod out of selector lever upper section.



30 25 020


*Installation:*  
Check gate, replacing if necessary.



20 25 030

### 25 16 080 REMOVING AND INSTALLING SELECTOR LEVER — Version with Shift Rod —


Remove selector lever complete with base —  
see 25 16 050.  
Drive out pin.



20 25 023


Pull out selector lever lower section.  
Remove washer (1) and bearing sleeves (2).

*Installation:*  
Check bearing sleeves, replacing if necessary  
and lubricating with Molykote Longterm 2.



20 25 024

Pull off plug (3).  
Disconnect scale light wire (4).  
Unscrew screw (5).  
Remove transmission switch together with  
the upper selector lever section.



30 25 018

*Installation:*  
Check installed position of transmission  
switch and drive.



20 25 026

## 25-21


### 25 16 202 REPLACING CABLE FOR SELECTOR LEVER

Remove center console – see 51 16 200.  
Lift out retainer.  
Unscrew eye on pin.  
*Important!*  
Don't bend the steel wire.




30 25 036

Unscrew nut.  
Disconnect cable sleeve in holder.



30 25 037

Loosen nuts.  
*Important!*  
Don't bend the steel wire.



30 27 093

Unscrew nuts.  
Push back cable sleeve and disconnect in holder.  
Pull cable out of operating lever.




30 27 094

Pull out rubber grommet with cable upwards.



20 25 051

*Installation:*  
Check for correct seating of rubber seals after finishing installation.



30 25 051

*Installation:*  
Adjust cable.  
Shift lever in "P" (most forward position).  
Press shift lever opposite forward direction.  
Clamp cable rod without tension.  
*Important!*  
Tightening torque = 10 to 12 Nm (7 to 9 ft. lbs.).  
Don't bend the cable.



30 25 050

# 26 Propeller Shaft

26 11 000	Propeller shaft vibration and noise — eliminate .....	26 - 1
	Propeller shaft — remove and install .....	26 - 3
	Propeller shaft — remove and install (all wheel drive) .....	26 - 5
051	Propeller shaft joint (rear) — replace .....	26 - 6
	Propeller shaft joint (rear) — replace (all wheel drive) .....	26 - 8
	Propeller shaft joint (front) — replace (propeller shaft removed) .....	26 - 9
501	Propeller shaft center mount assembly — replace .....	26 - 10
26 12 001	Propeller shaft center mount assembly — replace .....	26 - 12
26 20 000	Propeller shaft (front) — remove and install (all wheel drive) .....	26 - 13
020	Propeller shaft cap (front) — replace (all wheel drive) .....	26 - 14
051	Propeller shaft joint (front) — replace (all wheel drive) .....	26 - 15
	Propeller shaft — troubleshoot .....	

## 26-1



### ELIMINATING PROPELLER SHAFT VIBRATION AND NOISE

#### Requirements:

Elimination of disturbances from faulty engine and transmission mounts, tension in exhaust assembly, etc... Propeller shaft in perfect optical and mechanical condition.  
Balance or replace propeller shaft. If balance plates are missing or propeller shaft is suspected to have imbalance (refer to instructions supplied with balancing equipment).

#### Caution!

A jacked up car may only be tested operated when the suspension of driven wheels is supported (deflection angle of output shafts).  
Never exceed the maximum speed specified for a car jacked up or on a dynamometer.  
Conform with safety regulations!



Move transmission to the side until the special tool gage shows equal spacing on left and right sides.

#### Checking Propeller Shaft Deflection

##### Angle:

Remove exhaust assembly, heat shield and, if applicable, splash guard.

Place Special Tool 26 1 030 on an engine surface running perpendicular or parallel to the crankshaft.  
Set the indicator perpendicular with help of the water scale.  
Read degrees.



##### Note:

Always apply the gage with the scale in the same direction (e.g. scale right).  
One graduation = 5°.  
The position of the car is not important, since only separate angles are compared.



The following bearing surfaces are applicable depending on engine type and version.  
Place Special Tool 26 1 030 on the oil pan flange and determine the angle of engine inclination.

#### Centering Propeller Shaft:


Loosen the exhaust assembly, engine mounts and transmission cross member.  
Apply Special Tool 26 1 020.



**Application Points:**  
Checkpoints on engine carrier at rear.  
With manual transmission - middle of cast rib.  
With automatic transmission - middle bolt of transmission extension.  
(Punch mark the pertinent checkpoint.)



## 26-2



30 26 0 12

### Hard Movement on Slide - - Slide on Center Mount -


**Important!**  
The propeller shaft was balanced in assembled state and must not be turned in the slide. Mark position of propeller shaft sections to each other.  
Remove threaded sleeve (1), washer (2) and rubber ring (3).  
Check rubber ring, replacing if necessary.  
Disconnect propeller shaft on slide.  
Clean and lubricate keyway with Molykote Longterm 2.\*\*  
Assemble propeller shaft that marks are in one plane.



30 26 0 40

### Hard Movement on Slide: - Propeller Shaft for All Wheel Drive -

**Important!**  
The propeller shaft was balanced in assembled state and must not be turned in the slide. Mark position of propeller shaft sections to each other.  
Remove threaded sleeve (1), washer (2) and rubber ring (3).  
Check rubber ring, replacing if necessary.  
Disconnect propeller shaft on slide.  
Clean and lubricate keyway with Molykote Longterm 2.\*\*  
Assemble propeller shaft that marks are in one plane.  
**Installation:**  
Check seal in dust cap, replacing if necessary.



30 26 0 25

**Note:**  
Propeller shaft sections are mounted in such a manner that universal joints are in one plane.  
If the slide had been disassembled by mistake without marking, it will only mean the possibility of installing the propeller shaft wrong by 180° because of balancing.

After finishing installation:  
Tighten threaded sleeve with Special Tool 26 1 040.  
Tightening torque\*.




30 26 0 05

\* See Specifications  
\*\* Source of Supply: HWB



30 26 0 39



30 26 0 38

- 1 Front propeller shaft section
- 2 Rear propeller shaft section
- 3 Clamping nut
- 4 Clamp
- 5 Washer
- 6 Dust cap
- 7 Seal

\*\* Source of Supply: HWB

## 26 - 16

### TROUBLESHOOTING PROPELLER SHAFT

Condition	Cause	Correction
Drumming from 60 km/h (35 mph) on	Propeller shaft not aligned precisely or installed with stress — axial compensator	Align propeller shaft or check movement of axial compensator, lubricating slide with Molykote Longterm 2 and tightening screw-on bushing to correct torque* if necessary
	Center damaged	Replace center — 26 11 501
	Runout on centering pin, transmission or final drive flanges	Check centering pin and flanges for runout with dial gage — see Specifications; offset or replace final drive flange
	Centering error due to worn flange bores (loose bolts)	Replace transmission or final drive flange
	Excessive propeller shaft imbalance, balance plate missing	Balance or replace propeller shaft — see 26 11 000
	Universal joints worn or seized	Check clearance and movement, replacing propeller shaft if necessary
Center mount noise while driving	Center mount not perpendicular to propeller shaft; no or insufficient preload	Preload center mount 4 to 6 mm (0.157 to 0.236") in forward direction at right angle to propeller shaft
	Center mount grooved ball bearing not okay	Replace grooved ball bearing — 26 12 001

\* See Specifications

# 27 Transfer Box

27 10 000	Visco central lock – check in car	27 - 1
010	Transfer box – remove and install (manual transmission)	27 - 4
010	Transfer box – remove and install (automatic transmission)	27 - 7
	Transfer box gear wheel set layout drawing	27 - 11
23 71 003	Transfer box – disassemble and assemble	27 - 12
503	Rubber mounts for transmission suspension – replace	27 - 23
	Rubber mounts for transmission suspension – replace	27 - 25



27 10 000 CHECKING CENTRAL LOCK IN CAR

The condition of a central lock can be checked on a brake test stand with help of the BMW service tester.

**Caution!**  
If only one axle turns in a test on the brake test stand, the central lock will be subjected to strong loads and could be destroyed from excessive heat.


Never exceed the total running time = warm-up time + test time of 60 seconds on the brake test stand.

Make a break of at least 30 minutes after each test cycle. These times are applicable to cold and warm operated cars.


The roller speed of the brake test stand must not exceed 7.5 km/h (4.5 mph).

If the roller speed of the brake test stand without load is not known, it can be determined with a '3' series car with ABS, but without all wheel drive, to the methods described in the testing procedures. In so doing the warm-up phase and measuring the braking force are omitted.

Check the inflation pressure and tire size. Park rear wheels of car in test stand rollers. Front wheels are on floor. Shift lever in neutral.




30 27 002




Car must be connected on the BMW service tester, to determine test stand speed (wheel speed) under load. Switch off electric equipment and ignition. Connect T-plug (4) between ABS control unit (2) and ABS wire harness (1).

30 27 003




30 27 004

Select test program 03 ABS on BMW service tester.  
Select ABS test step 03.  
Turn on ignition.



30 27 005

Switch on both rollers of brake test stand. Run brake test stand approx. 40 seconds (warm-up phase).




30 27 008

Press reset button on BMW service tester after the warm-up time. The value in ms now appearing at rear left or right is equal to the roller speed. See diagram.

Read braking force of both wheels on brake test stand and add.

**Caution!**  
Total running time: max. 60 seconds.




30 27 006

# 27-3

## VISCO CENTRAL LOCKS DIAGNOSIS

Number of pulse wheel teeth: 48.  
 Rear axle in brake cylinder.  
 Front axle standing.  
 Warm-up time: approx. 40 sec..  
 Testing time: max. 20 sec..  
 Total testing time: max. 60 sec..  
 Test immediately after warm-up phase!  
 Time between 2 tests: at least 30 minutes.

No. of pulse wheel teeth 48  
 Rear wheels in brake rollers  
 Front wheels on floor  
 Warm-up time approx. 40 sec.  
 Test time max. 20 sec.  
 Total test time max. 60 sec.  
 Testing immediately after warm-up phase!  
 At least 30 minute break between 2 tests.






**Installation:**  
 Replace stop nuts.  
 Tightening torque\*.  
**Important!**  
 Only tighten nuts or bolts on the flange end, whenever possible by design, to avoid tension in the joint disc.




Push propeller shaft together and pull out of centering pin on the transfer box.  
**Note:**  
 Propeller shaft was balanced in assembled state and therefore may only be replaced complete.  
 Never unscrew propeller shaft on the slide.




**Installation:**  
 The seal could slip out of the protective cap while pulling the propeller shaft apart. Prevent this by holding the seal on the bearing surface of the screwed-on sleeve with grease.

30 27 101


**Important!**  
 Don't let the propeller shaft bear on the fuel tank connecting pipe.




\* See Specifications



Unscrew joint disc between manual transmission and transfer box on the output flange of the manual transmission.




**Installation:**  
 Replace stop nuts.  
 Tightening torque\*.  
**Important!**  
 Only tighten nuts or bolts on the flange end, whenever possible by design, to avoid tension in the joint disc.



Support transmission from underneath.  
 Unscrew cross member.  
**Note:**  
 Bolts differ in length.

Lower transmission.  
 Unscrew bolts.

**Note:**  
 The upper bolts are accessible with a 17 mm wrench socket, joint and extension in 3/8" version.




\* See Specifications

## 27-7

### 27 10 010 REMOVING AND INSTALLING

TRANSFER BOX  
— All Wheel Drive Cars with  
Automatic Transmission —

Remove exhaust assembly — see 18 00 020.  
Unscrew heat shields.



30 27 010

Unscrewing Rear Propeller Shaft Section:  
Loosen screwed-on sleeve several turns with  
Special Tool 26 1 060.




30 27 090

**Installation:**  
Tighten screwed-on sleeve with Special Tool  
26 1 060 after finishing installation.  
Tightening torque\*.




30 27 091

Unscrew propeller shaft on transfer box.



30 27 012

\* See Specifications



30 27 013

**Installation:**  
Replace stop nuts.  
Tightening torque\*.

**Important!**  
Only tighten nuts or bolts on the flange end,  
whenever possible by design, to avoid tension  
in the joint disc.


Push propeller shaft together and pull out of  
centering pin on the transfer box.

**Note:**  
Propeller shaft is balanced in assembled state  
and therefore may only be replaced complete.  
Never unscrew propeller shaft on the slide.



30 27 014

**Installation:**  
The seal could slip out of the protective cap  
while pulling propeller shaft sections apart.  
Prevent this by holding the seal on the bearing  
surface of the screwed-on sleeve with grease.



30 27 101

**Caution!**  
Don't let the propeller shaft bear on the fuel  
tank connecting pipe.




30 27 015

\* See Specifications

## 27-9

Pull off transfer box toward rear.

*Installation:*  
Mesh spines of front propeller shaft section by turning.



*Installation:*

Check sealing surfaces.

Replace gasket.


Check dowel pins in transfer box.

Check oil level after finishing installation, correcting if necessary.

Fill automatic transmission with ATF.

## 27-12

00 1 490 27 1 000



30 27 024

27 10 ... DISASSEMBLING AND ASSEMBLING TRANSFER BOX

### Disassembling Transfer Box:

Mount Special Tool 27 1 000 on Special Tool 00 1 490.

Bolt transfer box on Special Tool 27 1 000.

Manual Transmission:

Three M 10 x 4 bolts with nuts.


Automatic Transmission:

Two M 8 x 40 bolts with nuts.

Drain oil.


Old Special Tool 27 1 000 has to be machined for automatic transmission versions.

Drive out the dowel pin.




30 27 108

Screw special tool holder on shown bore with a M 8 x 40 bolt only finger tight.




30 27 109

Position holder in such a manner, that a new 10 mm (0.394") dia. hole can be drilled about 5 mm (0.197") away from the old hole.  
Mark center point, drill 10 mm (0.394") dia. hole and deburr edges of hole.




30 27 110

Drive dowel pins out of case at rear.




30 27 025

Unscrew all bolts.



30 27 026


Knock off rear case with uniform knocks from a nylon hammer on the webs.  
Lift off rear case.  
Remove gasket.



30 27 027


# 27-14

Pull off sprocket, driving off the front drive sprocket with a plastic hammer at the same time.  
*Important!*  
Don't cant the chain.



30 27 036


**Automatic Transmission:**  
Insert Special Tool 27 1 250 in the sprocket main shaft.  
Drive out both shafts uniformly with a plastic hammer.  
*Important!*  
Don't cant the chain.



30 27 111

Lift off sprockets with chain.

*Note:*  
Mark running direction of chain, if it can be reused.




30 27 037

*Note:*  
Grooved ball bearing will remain on the sprocket or in the case, depending on tolerances.  
Pull off grooved ball bearing, if necessary.




30 27 038

**Manual Transmission:**  
Lift out circlip.  
Pull out drive shaft.



30 27 039

Pull out grooved ball bearing, if applicable.  
Remove shaft seal (two for automatic transmissions).



30 27 040

**Automatic Transmission:**  
Pull off clamp.



30 27 123

Pull off cap.  
Remove vent.  
Check O-ring.



30 27 124


# 27-16



30 27 113

*Note:*  
Grooved ball bearing remains on shaft or in case, depending on tolerances.  
Lift off washer, if applicable.  
Pull off grooved ball bearing.  
Curved surface of washer faces the output flange.

Lift off washer and visco clutch.



30 27 047

Lift out circlip.




30 27 048

Lift output shaft off of hollow gear wheel.



30 27 049




30 27 050

Remove both grooved ball bearings in case.



30 27 114


Lift out vent.



30 27 115



Unscrew oil baffle plate.






**Automatic Transmission:**  
 Bearing collar (3) is omitted on the case since 11.87 for assembling reasons.  
 Radial oil seals can be installed from the outside.  
 Check installed position.  
 Drive in radial oil seal (1) with Special Tools 27 1 270 and 27 1 271 - sealing lip facing IN.  
 Drive in radial oil seal (2) with Special Tool 27 1 270 - sealing lip faces OUT.  
 Leak oil bore (4) must not be covered.

**Heat case.**  
 Install both grooved ball bearings with Special Tool 33 1 230.




**Manual Transmission:**  
 Place input shaft in case.  
 Install circlip.  
*Note:*  
 Input shaft is guided only by the radial oil seal or guide pin on the manual transmission.



Mount sprockets complete with chain (check running direction if applicable).  
 Drive both sprockets into bearings with a plastic hammer at the same time.  
*Important!*  
 Don't cant the chain.



**Apply slip sleeve of Special Tool 27 1 080.**  
 Install the first radial oil seal with the sealing lip facing IN.  
 Drive in radial oil seal with Special Tool 27 1 080.



Install the second radial oil seal with the sealing lip facing OUT.  
 Drive in both radial oil seals with Special Tool 27 1 080.

*Note:*  
 The second radial oil seal is installed without a spiral spring. Parts only supplies radial oil seals with spiral springs. When replacing, it is therefore necessary to remove the spiral spring for the outside radial oil seal.

Install circlip and O-ring.




# 27-20

Insert output shaft in hollow gear wheel.  
Install circlip.




30 27 067

Mount visco clutch and washer.



30 27 068

Insert output shaft in case.  
Apply Special Tools 27 1 120 and 23 1 300.  
Pull output shaft into case.




30 27 069

Install radial oil seal with Special Tool 27 1 090.



30 27 070

Mount and screw on damper.




30 27 121

Mount output flange.  
Coat threads with a bolt cement\*\*.  
*Important!*  
Use a new collar nut.  
Screw on new collar nut.



30 27 071

Apply Special Tool 23 1 200.  
Hold output flange with Special Tool 23 0 020.  
Tighten collar nut with Special Tool 23 1 210.  
Tightening torque\*.



30 27 072

Lock collar nut in the provided recess.




30 27 073

\* See Specifications  
\*\* Source of Supply: HWB


## 27-22

Install gasket and seal.



30 27 078

Mount rear case on front case section.




30 27 079

Turn the output flange (while holding the input flange) to have the planet gear set mesh. Pins on the drive shell must engage in recesses of the visco clutch.




30 27 080

Insert bolts (bolts have different lengths). Drive the case sections together by applying light knocks with a plastic hammer in the front output shaft end area.



30 27 081

Drive in dowel pins.




30 27 082

Tighten bolts in several steps. Tightening torque\*.



30 27 083

Pour in oil\*.



30 27 084

Pour part of the oil (0.06 dm<sup>3</sup>) into the vent bore after removing the vent of a rammed transmission in case of a completely drained transmission, e.g. after disassembling a transmission. This will guarantee the supply of oil to the rear transmission section when operated initially. The remaining amount of oil should be poured in through the filler neck after installation of the transmission. If too much oil is poured in through the vent, it will flow via the baffle plate to the front axle drive and does not have to be compensated there. Always replace a vent, which has been removed.

\* See Specifications

## 27-24

**Installation:**  
Mount new rubber mount.  
Arrow on case must be aligned with mark  
(bead) on rubber mount.  
Protruding inner bushing faces toward  
rear.



Apply Special Tool 27 1 190.



Press in rubber mount flush with transmission  
case.

